

IMPORTANT

Seal all connectors with Dielectric Grease (part MX959) or Silicone Lubricant (supplied)



© ALARM LOCK 2009





Trilogy T2 DL2700 & TL2700 Programming Instructions

Mortise, Cylindrical & Exit Trim Locks

OI209D.aLF 3/25

CONGRATULATIONS!

Your new Alarm Lock Trilogy electronic digital lock is a rugged entry lock of advanced design with several programmable features.

The 2700 series features two models that are identical in operation but with different keypad types: The traditional DL2700 with a standard keypad with pressable buttons and the TL2700 with a flat touchsensitive touchpad that illuminates when touched.

The lock provides three types of codes: **Master** (can perform ALL functions), **Manager** (can perform MOST functions plus entry through the door), and **Basic User** (entry only). The lock includes 100 codes (consisting of Manager and Basic), plus three one-time

entry "Service Codes". As you will see in the following pages, the codes are organized in a grid -ten banks (columns) of ten codes (rows).

Take the time to read through this guide to familiarize yourself with its features, operations and programming steps.

Features (both models)

- 1 Master Code (all functions including entry)
- 10 Manager Codes (perform MOST programming functions plus entry)
- 90 Basic Codes (entry only)
- 3 Service Codes ("one-time entry" codes)
- Two User Disable Modes:
 - All Codes Disabled Except Master Code
 - All Codes in a Bank Disabled Except Manager Codes
- 30-Second Keypad Anti-Tamper Lockout: (Keypad Lockout After 3 Unsuccessful Code Entries)
- Programmable Relay Functions: (Relay may be keypad-programmed to energize on any keypress (0-9) or on unlock).

Model TL2700 Touchpad Features

Identical to the DL2700 above, but includes:

- Touch-sensitive instant-on back-lit screen
- Extremely resistant to dirt, water and most chemicals
- Designed for effortless, long-lasting operation





DL2700 (Cylindrical with Standard Keys)

TL2700 (Cylindrical with Touch keypad)

QUICK LOOKUP

Wiring	2
Quick Start	2-3
Testing Codes	3
Manager & User Location Worksheet	4
Manager & User Location Example	5
Programming Worksheet: Functions	6
Change Existing Master Code	7
Add/Change Manager Codes	7
Add/Change User Codes	7
Deleting Codes	7
Disable/Enable Users	7
Disable/Enable All	8
Code Location Function	8
Next Free Code Address Locator	8
Add/Delete Service Codes	9
Enable/Disable Passage Mode	9
Pass Time ("Door Unlock")	9
Disable/Enable Groups	9
Disable/Enable Users in Bank	10
Keypress Sound Options	10
AUX Relay Functions	10
Lock Identifier	10
Enable / Disable Emergency Chirp	11
Remote Switch Input Wires Toggle	
Passage Mode	11
Audible and LED Indications	11
Battery Replacement	12
Erase All Programming	12
Extra Manager & User Location Worksheets	. 13-15
Limited Warranty	16

Wiring

See the Installation Instructions for more information.

Batteries:

Use only 1.5 volt Duracell Alkaline size-AA batteries.

External Power:

An external 7.5 VDC Power Source, capable of at least 100mA, must be used for operation without batteries in the lock. Use an external UL-Listed power supply provided with backup battery power and current limiting protection that is approved for the application.

BLACK = Negative, RED = Positive.

Aux Relay:

Aux Relay allows up to 300mA @ 60VDC Maximum. See page 10 for programming options for the Relay ("AUX Relay Functions").

BLUÉ = Common, YELLOW = \dot{N}/O , GREEN = N/C.

Remote Switch Input (2 White Wires)

A remote momentary switch can be wired to allow access through the door when activated. Wire a normally open push button switch to the two white wires (depress (close) the push button for one second to unlock the unit).

Quick Start

First Time Start Up

Failure to follow this exact procedure can result in erratic lock behavior. **Note:** When entering key sequences, *do not pause more than 5 seconds between key entries or you must start again.*

- 1. With batteries disconnected, press/hold down a numeric key for 10 seconds and release.
- 2. Connect batteries and within 3 seconds press/hold down **C**. After hearing 6 beeps, release **C**. Wait 5 seconds for lock to re-lock (listen for 1 beep with a red LED). The lock is now ready for programming.
- 3. The Factory Master Code **MUST** be changed as described in the next section.

Change Factory Master Code

The Master Code is your "secret" code entered at the keypad that allows you to change ALL programming functions and options. Because all locks are manufactured with the *same* Master Code, this "factory" Master Code is not "secret", and therefore MUST be changed to ensure security. Your Master Code may contain between 3-6 digits but we recommend using 5 - 6 digits. **Note:** The number of digits in your new Master Code will determine the number of digits required for ALL subsequent codes added.

We recommend reading the steps below before performing them.

- 1. Enter the factory Master Code: 1 2 3 4 5. A beep will sound and the lock will open.
- 2. Within 5 seconds, enter II II.
- 3. Within 5 seconds, enter your new Master Code and press .
- 4. Re-enter your new Master Code. Listen for a 6-beep acknowledgement (with a red LED), then wait 5 seconds for lock to re-lock.
- 5. Test your new Master Code: Enter your new Master Code and listen for a beep and for the lock to unlock.

If you wish, write your new Master Code in the spaces below:

12345		
	Your new Master Code	(Repeat)

Enter "Manager" Codes

Before proceeding, we recommend reading the description of the grid on page 4. Basic Codes only allow access through the door. Manager Codes allow access and ALSO have the ability to program and delete Basic Codes within that Manager's Bank (column) and also for all higher Banks until the next programmed Manager Code appears in a higher Bank.

The lock can hold up to 10 Manager Codes, one for each Bank (Manager Codes are located in locations (00), (10), (20), (30), (40), (50), (60), (70), (80), (90)), all located at the top row of the grid. **Note:** Only the Master Code can add or delete a Manager Code.

Continued

^{*} After the number of digits is selected, it cannot be changed unless all programming is erased and the Factory Default settings are re-loaded using the "Erase All Programming" procedure found on page 12.

Quick Start (cont'd)

Before adding Manager Codes, read the steps below before performing them.

- 1. Enter your previously programmed new Master Code.
- 2. Enter followed by a selected Manager location (i.e., 00, 10, 20, 30, 40, 50, 60, 70, 80, or 90).
- 3. Enter a new Manager Code *using the same number of digits as your new Master Code*. A 6-beep acknowledgement (with a red LED) will sound. Wait 5 seconds for lock to re-lock (if the lock remains unlocked, repeat from step 2, otherwise restart from step 1 for each new Manager Code). If you wish, write a new Manager Code in the space below:



Enter "Basic" Codes

Basic Codes only allow entry through the door. Duplicate codes are not allowed. Enter Basic Codes in any order you wish.

We recommend that you read the steps below before performing them.

- 1. Enter your previously programmed new Master Code or associated Manager Code.
- 2. Enter [[enter a 2-digit location number] [].
- 3. Enter a new Basic Code *using the same number of digits as your new Master Code*. A six-beep acknowledgement (with a red LED) will sound. Wait 5 seconds for lock to re-lock (if lock remains unlocked, repeat from step 2; otherwise restart from step 1).

Example: Add a Basic Code of "22222" in location "01", enter:

[Master or associated Manager C	Code] 💷	$\bigcirc \bigcirc \bigcirc$	\square	2	22	2
---------------------------------	---------	------------------------------	-----------	---	----	---

Delete a Code

The Master Code can be *changed* but cannot be *deleted*. <u>Manager</u> Codes can only be deleted using the Master Code. If the location of the code is unknown, use the *Code Location Function* on page 8.

- 1. Enter the Master Code or associated Manager Code.
- 2. Enter [enter the 2-digit location number] [. A six-beep acknowledgement (with a red LED) will sound. Wait 5 seconds for lock to re-lock (upon re-lock the code will be deleted). If lock remains unlocked, repeat from step 2; otherwise restart from step 1 for each code you want to delete.

Example: Delete a Basic Code in location 47, enter:

[Master or associated Manager Code	e) 🛈 🕘 🗇 🛈	*
------------------------------------	------------	---

Testing Codes

- VALID CODE The Green LED will flash (with 1 beep) after a valid code is entered. The lock will unlock immediately and remain unlocked for about 5 seconds (this "unlocked" time is the "Pass Time"). To make the Pass Time longer or shorter, use the Pass Time Function on page 9. Note: While the lever or knob may be rotated at any time, the latch will not be engaged to unlock the door unless a valid code is entered at the keypad.
- **INVALID CODE** The Red LED will flash 5 times (with 5 beeps) after an invalid code is entered. (To quickly clear a miskeyed or invalid code, enter and immediately re-enter the correct code).
- **KEYPAD ANTI-TAMPER LOCKOUT -** If 3 invalid codes are entered in succession, the lock will enter Anti-Tamper mode by turning off for approximately 30 seconds to prevent tampering. The lock will emit 2 beeps with a Red LED flash warning at the end of the Anti-Tamper mode period. The lock will exit Anti-Tamper mode immediately upon activation of the Remote Switch Input (white wires). **Note:** The lock will go into Anti-Tamper mode after 3 unsuccessful code entries *even if entered by different users and spaced apart in time*. Therefore, the lock may "appear" to go into Anti-Tamper mode lockout *even after the entry of just one invalid code*.

This lock provides three types of codes: **Master** (can perform ALL functions), **Manager** (can perform SOME programming functions plus entry through the door), and **Basic User** (entry only). In total, there are 104 "locations" inside the lock: One Master Code, 10 Manager Codes, 90 Basic Codes, and three one-time entry "Service Codes". <u>Where</u> the Code is located determines its programming abilities. From the factory, all locations (except for the Master Code) are empty; each location can then be programmed to contain a code to allow users to program and/or unlock the lock to allow entry.

As a visual aid, these code locations are shown in the grid below, with ten "Banks" (columns) of ten "Managers/Basic Users" in the rows (the grid excludes the Master Code and the 3 Service Codes). Each of the 100 squares in the grid is identified by a unique two-digit location (00) through (99). Notice the two digits also specify its Bank (column) and row location in the grid. Also notice that all Managers are in the top row, their locations all ending in a zero (locations 00, 10, 20, 30 and so on through 90). Use the blank grid below as a worksheet for preparing all programming in advance. Store this worksheet in a safe place for future reference.

	BANK 0	BANK 1	BANK 2	BANK 3	BANK 4	BANK 5	BANK 6	BANK 7	BANK 8	BANK 9
NAGERS	MGR 00	MGR 10	MGR 20	MGR 30	MGR 40	MGR 50	MGR 60	MGR 70	MGR 80	MGR 90
BASIC ISERS →	USER 01	USER 11	USER 21	USER 31	USER 41	USER 51	USER 61	USER 71	USER 81	USER 91
	USER 02	USER 12	 USER 22	USER 32	USER 42	USER 52	USER 62	USER 72	USER 82	USER 92
,										
BASIC JSERS →	USER 03	USER 13	USER 23	USER 33	USER 43	USER 53	USER 63	USER 73	USER 83	USER 93
BASIC JSERS →	USER 04	USER 14	USER 24	USER 34	USER 44	USER 54	USER 64	USER 74	USER 84	USER 94
BASIC JSERS →	USER 05	USER 15	USER 25	USER 35	USER 45	USER 55	USER 65	USER 75	USER 85	USER 95
BASIC JSERS →	USER 06	USER 16	USER 26	USER 36	USER 46	USER 56	USER 66	USER 76	USER 86	USER 96
BASIC JSERS →	USER 07	USER 17	USER 27	USER 37	USER 47	USER 57	USER 67	USER 77	USER 87	USER 97
BASIC JSERS →	USER 08	USER 18	USER 28	USER 38	USER 48	USER 58	USER 68	USER 78	USER 88	USER 98
BASIC JSERS	USER 09	USER 19	USER 29	USER 39	USER 49	USER 59	USER 69	USER 79	USER 89	USER 99

Manager & Basic User Location Example

Basic Codes only allow access through the door. Manager Codes allow access and ALSO have the ability to program and delete Basic Codes within that Manager's Bank (column) *and also for all higher Banks until the next programmed Manager Code appears in a higher Bank*.

The lock can hold up to 10 Manager Codes, one for each Bank (locations (00), (10), (20), (30), (40), (50), (60), (70), (80), (90)), all located at the top row of the grid below. **Note:** Only the Master Code can add or delete a Manager Code.

In the example grid below, if Manager Codes are programmed for locations (00) and (60), then the Manager in location (00) has control of all gray-shaded locations (00-09, 11-19, 21-29, 31-39, 41-49, and 51-59). The Manager in location (60) then has control over the black-shaded locations (61-69, 71-79, 81-89, and 91-99).

Note: If you wish to grant any Manager the ability to program any User, use the "Disable Groups" Function on page 9 (enter the Master Code, then enter 2 2 1.

Mana Progra	ger Code mmed here						ſ	Manager Co Programmed	ode here	
<u> </u>	(BANK 0)	(BANK 1)	(BANK 2)	(BANK 3)	(BANK 4)	(BANK 5)	(BANK 6)	(BANK 7)	(BANK 8)	(BANK 9)
MANAGERS →	MGR 00	MGR 10 (BLANK)	MGR 20 (BLANK)	MGR 30 (BLANK)	MGR 40 (BLANK)	MGR 50 (BLANK)	MGR 60 🖌	MGR 70 (BLANK)	MGR 80 (BLANK)	MGR 90 (BLANK)
BASIC USERS →	USER 01	USER 11	USER 21	USER 31	USER 41	USER 51	USER 61	USER 71	USER 81	USER 91
BASIC USERS →	USER 02	USER 12	USER 22	USER 32	USER 42	USER 52	USER 62	USER 72	USER 82	USER 92
BASIC USERS →	USER 03	USER 13	USER 23	USER 33	USER 43	USER 53	USER 63	USER 73	USER 83	USER 93
BASIC USERS →	USER 04	USER 14	USER 24	USER 34	USER 44	USER 54	USER 64	USER 74	USER 84	USER 94
BASIC USERS →	USER 05	USER 15	USER 25	USER 35	USER 45	USER 55	USER 65	USER 75	USER 85	USER 95
BASIC USERS →	USER 06	USER 16	USER 26	USER 36	USER 46	USER 56	USER 66	USER 76	USER 86	USER 96
BASIC USERS →	USER 07	USER 17	USER 27	USER 37	USER 47	USER 57	USER 67	USER 77	USER 87	USER 97
BASIC USERS →	USER 08	USER 18	USER 28	USER 38	USER 48	USER 58	USER 68	USER 78	USER 88	USER 98
BASIC USERS →	USER 09	USER 19	USER 29	USER 39	USER 49	USER 59	USER 69	USER 79	USER 89	USER 99

Programming Worksheet: Functions

The "factory" Master Code (1-2-3-4-5) must first be changed to a new Master Code before any other programming can take place. All new codes must have the same number of digits as the new Master Code. Choose new codes and write them in spaces provided below (in pencil) before programming the lock. 6 beeps will usually be heard after a valid entry.

FUNCTION	KEYPAD ENTRIES
Change Existing Master Code	[Enter Factory or Existing Master Code] [[Enter New Master Code] [[Re-enter New Master Code] [6 beeps = OK]
Add/Change Manager Codes (up to 10)	[Enter Master Code] [Enter 2-digit Manager Location] [Inter new Manager Code] [6 beeps = OK]
Add/Change Basic Codes (up to 90)	Enter Master or Manager Code [1] [Enter 2-digit Location]
Deleting Manager & Basic Codes	Enter Master or Manager Code 💶 [Enter Bank Number] [Enter User Number] 💷 💌
Disable / Enable User Number (Toggle)	Enter Master or Manager Code 💷 [Enter Bank Number] [Enter User Number] 💷 (wait)
Disable All	Enter Master or Manager Code 💶 🧐 55 5 😰 (Reset with "Enable All" Function 944)
Enable All	Enter Master or Manager Code 1 9 4 4
Disable Users Only	Enter Master or Manager Code 💶 🧐 5 💽 💷 (Reset with "Enable All" Function 944)
Code Location Function	Enter Master or Manager Code
Next Free CodeAddress Locator	Enter Master or Manager Code 💶 🔽 [Responds with Bank # and User #]
Service Code 1	Enter Master or Manager Code 💷 🛐 💽 🗊 💷 [Enter new Service Code]
Service Code 2	Enter Master or Manager Code 💷 🛐 💽 😰 📭 [Enter new Service Code]
Service Code 3	Enter Master or Manager Code 💷 🛐 💽 🕄 💷 [Enter new Service Code]
Clear Service Codes	Enter Master or Manager Code 💷 🛐 💽 💽
Enable Passage Mode	Enter Master or Manager Code 💶 🖪 💷
Disable Passage Mode	Enter Master or Manager Code 💶 互 💷
Pass Time ("Door Unlock")	Enter Master Code 💶 4 [Enter "02" - "20" seconds]
Enable Groups	Enter Master Code 💷 🔼 🚺 💽
Disable Groups	Enter Master Code 💶 💶 💶 💷
Disable Users In Bank	Enter Master or Manager Code 💶 📧 🗔 [Enter Bank Number (0-9)] 💷
Enable Users in Bank	Enter Master or Manager Code 💶 📧 4 [Enter Bank Number (0-9)]
High Freq KP Feedback + LED	Enter Master Code 💶 🔼 💽 💷
Low Freq KP Feedback + LED	Enter Master Code 💶 🔼 🚺 💷 (With Mortise locks: Keypress "clicks" and entry/error "beeps")
Click! KP Feedback + LED	Enter Master Code [1] [2] [2] [1] (With Mortise locks: Keypress "clicks" and entry/error silent)
LED Only ("library mode")	Enter Master Code 💶 2 2 3 💷 All lock models completely silent ("library mode")
Chirp on Emergency	Enter Master Code
No Chirp on Emergency	Enter Master Code 1 2 2 5 1 ("LD" Lock models with Emergency functions only)
Remote Switch Input Default (see page 2)	Enter Master Code 💶 🔼 🕄 💽 💷 (2 white wires operate normal remote release)
Remote Switch Input Toggle Passage	Enter Master Code 💶 🔼 🚺 💷 (Short beep = passage entry; long beep = passage exit)
Disable AUX Relay Function	Enter Master Code 💶 🔼 💽 💽
AUX Relay on any First Keypress (0-9)	Enter Master Code 💶 🔼 🚺 💷
AUX Relay When Unlocked	Enter Master Code 💷 🖸 😰 💷
Lock Identifier	[Any Digit] [Any Digit] [Isten for musical tones]

Programming Functions

Change Existing Master Code* 📧 🗊
For new locks, follow the "Quick Start" on page 2. The "Factory" Master Code MUST be changed. The Master Code allows lock configuration, passage through the door and user management functions.
Old (or "Eactory") Master Code New Master Code* Confirm New Master Code*
Add/Change Manager Codes 💷 [] 💽 💷
Follow the "Quick Start" on pages 2-3. Note: You can also add/change the Manager Code in loca- tion 00 by entering the Master Code, [1] [2] [1] then the new Manager Code. Allows passage through the door and user management functions
Image: And a contraining embiling embili
Add / Change Basic User Codes [] [] Follow the "Quick Start" on page 3.
Master Code or Manager Code** Master Code or Bank (Column) 0-9 New Basic User Code
Deleting Manager & Basic User Codes [] [] [] Follow the "Quick Start" on page 3.
Master or Manager Code** Imager Bank (Column) Manager Bank (Column) User (Row) Always zero for Managers 0-9 0-9
Disable / Enable Users (Toggle) Enter the Master Code to disable / enable any Manager or Basic User, or enter a Manager Code to disable any Basic User within the Manager's Bank.

Disable User Number	Master or Manager Code	Bank / User Number
Enable User Number	[] Master or Manager Code	Bank / User Number

* After the number of digits is selected, it cannot be changed unless all programming is erased and the factory default settings are re-loaded (i.e., power must be removed and re-applied as per the "Erase All Programming" procedure found on page 12.
 ** Required only if the unit is locked.

Enable / Disable All

- **Disable All:** If Master Code is used, disables all 100 Basic User / Manager Codes and clears all 3 Service Codes. If a Manager Code is used, disables all Users (even across multiple Banks) under that Manager.
- **Disable Users Only:** If Master Code is used, disables all 90 Basic Users and clears all 3 Service Codes, while Managers remain active. If a Manager Code is used, disables all Users (even across multiple banks) under that Manager.
- **Enable All:** If Master Code is used, re-enables all 100 Basic User / Manager Codes (Service Codes must be reprogrammed). If a Manager Code is used, re-enables all Basic Users (even across multiple Banks) under that Manager. **Note:** Managers cannot disable themselves. Use Function 944 to restore Functions 955 and 950. In addition, if codes are disabled using Function 955 or 950, and a new code is subsequently added (or an existing code changed), the new (or changed) code will automatically become enabled.



Code Location Function 💷 🙆 💷

Be sure to record all code locations in the blank worksheet (page 4; also pages 13, 14 and 15) for future reference. Use this function to find an unknown code location. The lock will identify the Bank (0-9) and User (0-9) by beeping and flashing the GREEN LED 0 to 9 times as described below. Note: When the Bank and/or User numbers are zero, the GREEN LED will not flash and the sounder will not beep.



If the code entered is recognized, the following sequence will occur:

- 1. At the start of the Code Location sequence, the lock will flash both the GREEN and RED LEDs and will emit a low tone.
- 2. The lock will identify the **Bank** number by flashing the GREEN LED and beeping the sounder from 0 -9 times.
- 3. To signify the end of the Bank number ID sequence, both the GREEN and RED LEDs will flash with a low tone.
- 4. The lock will identify the **User** number by flashing the GREEN LED and beeping the sounder from 0-9 times.
- 5. To signify the end of the Code Location function, both the GREEN and RED LEDs will flash with a low tone.

Note: If the code is not recognized, the lock will sound 5 beeps with a RED LED.

Next Free Code Address Locator 💷 🔽

Using the same method of beeps and flashes used in the Code Location Function, and dependent on the Master or Managers Code entered, the lock will report the next available address for code programming.



Report Sequence

Note: No LED flashes/sounder beeps represent the number zero.

- 1. At the start of this "next available address" locator function, both the GREEN and RED LEDs will flash with a low tone.
- 2. The lock will identify the **Bank** number by flashing the GREEN LED and beeping the sounder from 0 9 times.
- 3. To signify the end of the Bank number ID sequence, both the GREEN and RED LEDs will flash with a low tone.
- 4. The lock will identify the **User** number by flashing the GREEN LED and beeping the sounder from 0-9 times.
- 5. To signify the end of this function, both the GREEN and RED LEDs will flash with a low tone. If no free address is found, the lock will emit a programming error tone sequence.

Add/Delete Service Codes

Service Codes are "one-time-only codes"; after entering a Service Code into the keypad and the lock unlocks, that Service Code is deleted. If you wish, you can use the same Service Code up to 3 times by programming all three Service Codes with the same code sequence. **Note:** Service Codes are lost if power is removed. To delete a single Service Code, enter , enter Service Code number (301, 302 or 303), then enter .

Service Code 1			
	Master/Manager Code		New Service Code
Service Code 2	[]	C 302 C	[]
	Master/Manager Code**		New Service Code
Service Code 3	[]	L 303 L	[]
	Master/Manager Code**		New Service Code
Delete All Servic	ce Codes [ager Code**	

Enable/Disable Passage Mode

Allows passage <u>without</u> the need to enter a Code into the keypad.

Enable Passage Mode	Master or Manager Code**		("Unlocked")
Disable Passage Mode	Master or Manager Code**	() ()	("Normal Operation")

Pass Time ("Door Unlock")

The Pass Time is the time the lock stays unlocked after a valid code entry. Use this function to change the Pass Time from 02 to 20 seconds (default is 5 seconds). **Note:** The Pass Time will also determine the amount of time allowed between keypresses during programming.

Pass Time	[][
	Master Code**	Pass Time

Disable/Enable Groups

Disable Groups: All Managers can program all codes, regardless of Bank.

Enable Groups: (Factory default) Managers restricted to controlling only those codes within their own Bank (column), and all following Banks until another Manager appears in a higher Bank. Codes in Banks outside of that Manager's Bank cannot be programmed.

Disable Groups	Master Code**	
Enable Groups	Master Code**	

** Required only if the unit is locked.

Disable/Enable Users in Bank

Enter Bank number (0-9) to enable or disable all of the codes in a Bank (column). Entering a disabled code results in an accented five beep error tone (indicating the code is valid but disabled).



AUX Relay Functions

Program the functions below to activate the Auxiliary Relay on any numeric keypress (Function 201), or when the unit is unlocked (Function 202). In either case the Aux Relay will be active for the duration programmed in Pass Time. See page 2 for information regarding the wiring of AUX leads.

Disable AUX Relay Function [Master Code**]	
AUX Relay on Any First Keypress (0-9) [Master Code**]	
AUX Relay When Unlocked	Master Code**]	

Lock Identifier

To aid in distinguishing your lock model from earlier Alarm Lock versions, your lock model will respond to any two digits plus the 💌 key by (1) lighting the green LED and (2) playing a musical scale of 8 notes.



Enable / Disable Emergency Chirp

For lock models with Emergency Lockdown functions only, the lock can be made to sound a chirp when an Emergency command is in effect.



Remote Switch Input Wires Toggle Passage Mode

The two white Remote Switch Input wires can be programmed to Toggle Passage Mode. To revert back to the default Remote Switch Input operation, use Function 230.



Audible and LED Indications

When a key is entered, a beep will sound and a Red LED will flash. Other indications are:

- Access Granted: 1 beep and a Green LED flash. (When Pass Time ends, the unit locks with a beep and a Red LED flash).
- Invalid Code Entered: 5 beeps and 5 Red LED flashes.
- Disabled Code Entered: 5 beeps (with extended first beep) and 5 Red LED flashes.
- New Code Accepted: 6 beeps and 6 Red LED flashes.
- Programming Error: 2 sets of 5 beeps and 5 Red LED flashes.
- Return from Anti Tamper Lockout: 2 beeps with a Red LED flash.
- Low Battery: High/Low sounder with flashing Red LED for 5 seconds (see next page to replace batteries).

Note: Keypress tones may be disabled using the 💷 💷 💷 💷 command (see Keypress Sound Options, page 10).

Battery Replacement

When the batteries are weak and a key is entered, the lock will alert you by flashing the RED LED accompanied by a high/low sounder. The lock uses five AA-size 1.5 volt alkaline batteries; although the lock will function with weak batteries, be sure to replace them with fresh batteries as soon as possible.

- 1. Remove the screw at the rear of the lock housing and remove cover.
- 2. Remove battery pack and replace all 5 batteries.
- 3. Replace battery pack. Do not touch any keys for 10 seconds.

If you do not hear any beeps or if you hear 3 beeps (one per second), the previous lock programming is retained and the unit is ready for use.

4. Replace cover and tighten the cover screw to secure.

Erase All Programming--DL2700 (With Keypad Buttons)

Restore Factory Default (original settings that were set at the factory will be loaded).

- 1. Remove the battery pack, and with the batteries disconnected, press/hold down any numeric key for 10 seconds and release.
- 2. Connect the batteries and--within 3 seconds--press/hold down **(.**). After hearing 6 additional beeps, release **(.**).

The lock is now clear of all programmed data and is now ready to accept new programming. **Important:** If you do not hear these 6 beeps, you must start over at step 1.

Pailure to follow this exact procedure can result in erratic lock behavior.

Erase All Programming--TL2700 (With Touch Keypad)

Restore Factory Default (original settings that were set at the factory will be loaded).

- Important: Read the steps before performing them.
- 1. Remove and disconnect the battery pack (if equipped; remove all external power).
- 2. Touch/hold the number 5 for 3 to 5 seconds then release. Wait at least 15 seconds before proceeding.
- 3. Connect the battery and quickly touch/hold .
- Important: Upon power-up, the lock will sound 3 beeps; you MUST touch/hold Defore the 3rd beep.
- 4. A series of 6 rapid beeps signifies that the lock has been reset. The lock is now clear of all programmed data and is ready to accept new programming. **Important:** If you do not hear the 6 rapid beeps, you must start over at step 1.

Reminder: Prior to any other programming commands, you must first perform the "Change Factory Master Code" steps located on page 2.

Failure to follow this exact procedure can result in erratic lock behavior.

This lock provides three types of codes: **Master** (can perform ALL functions), **Manager** (can perform SOME programming functions plus entry through the door), and **Basic User** (entry only). In total, there are 104 "locations" inside the lock: One Master Code, 10 Manager Codes, 90 Basic Codes, and three one-time entry "Service Codes". <u>Where</u> the Code is located determines its programming abilities. From the factory, all locations (except for the Master Code) are empty; each location can then be programmed to contain a code to allow users to program and/or unlock the lock to allow entry.

As a visual aid, these code locations are shown in the grid below, with ten "Banks" (columns) of ten "Managers/Basic Users" in the rows (the grid excludes the Master Code and the 3 Service Codes). Each of the 100 squares in the grid is identified by a unique two-digit location (00) through (99). Notice the two digits also specify its Bank (column) and row location in the grid. Also notice that all Managers are in the top row, their locations all ending in a zero (locations 00, 10, 20, 30 and so on through 90). Use the blank grid below as a worksheet for preparing all programming in advance. Store this worksheet in a safe place for future reference.

Ea	ch square re C	presents a lo codes). Each	cation inside location car	the lock (ex hold one co	cluding the N de that can u	laster Code Inlock the lo	and the 3 Sei ck.	rvice		
	BANK 0	BANK 1	BANK 2	BANK 3	BANK 4	BANK 5	BANK 6	BANK 7	BANK 8	BANK 9
MANAGERS	MGR 00	MGR 10	MGR 20	MGR 30	MGR 40	MGR 50	MGR 60	MGR 70	MGR 80	MGR 90
BASIC USERS →	USER 01	USER 11	USER 21	USER 31	USER 41	USER 51	USER 61	USER 71	USER 81	USER 91
BASIC USERS →	USER 02	USER 12	USER 22	USER 32	USER 42	USER 52	USER 62	USER 72	USER 82	USER 92
BASIC USERS →	USER 03	USER 13	USER 23	USER 33	USER 43	USER 53	USER 63	USER 73	USER 83	USER 93
BASIC USERS →	USER 04	USER 14	USER 24	USER 34	USER 44	USER 54	USER 64	USER 74	USER 84	USER 94
BASIC USERS →	USER 05	USER 15	USER 25	USER 35	USER 45	USER 55	USER 65	USER 75	USER 85	USER 95
BASIC USERS →	USER 06	USER 16	USER 26	USER 36	USER 46	USER 56	USER 66	USER 76	USER 86	USER 96
BASIC USERS →	USER 07	USER 17	USER 27	USER 37	USER 47	USER 57	USER 67	USER 77	USER 87	USER 97
BASIC USERS →	USER 08	USER 18	USER 28	USER 38	USER 48	USER 58	USER 68	USER 78	USER 88	USER 98
BASIC USERS →	USER 09	USER 19	USER 29	USER 39	USER 49	USER 59	USER 69	USER 79	USER 89	USER 99

MASTER CODE

SERVICE CODE 1

SERVICE CODE 2

SERVICE CODE 3

LOCK DESCRIPTION

This lock provides three types of codes: **Master** (can perform ALL functions), **Manager** (can perform SOME programming functions plus entry through the door), and **Basic User** (entry only). In total, there are 104 "locations" inside the lock: One Master Code, 10 Manager Codes, 90 Basic Codes, and three one-time entry "Service Codes". <u>Where</u> the Code is located determines its programming abilities. From the factory, all locations (except for the Master Code) are empty; each location can then be programmed to contain a code to allow users to program and/or unlock the lock to allow entry.

As a visual aid, these code locations are shown in the grid below, with ten "Banks" (columns) of ten "Managers/Basic Users" in the rows (the grid excludes the Master Code and the 3 Service Codes). Each of the 100 squares in the grid is identified by a unique two-digit location (00) through (99). Notice the two digits also specify its Bank (column) and row location in the grid. Also notice that all Managers are in the top row, their locations all ending in a zero (locations 00, 10, 20, 30 and so on through 90). Use the blank grid below as a worksheet for preparing all programming in advance. Store this worksheet in a safe place for future reference.

Ea	ch square re C	presents a lo codes). Each	cation inside location car	the lock (ex hold one co	cluding the N de that can u	laster Code Inlock the lo	and the 3 Sei ck.	rvice		
	BANK 0	BANK 1	BANK 2	BANK 3	BANK 4	BANK 5	BANK 6	BANK 7	BANK 8	BANK 9
MANAGERS	MGR 00	MGR 10	MGR 20	MGR 30	MGR 40	MGR 50	MGR 60	MGR 70	MGR 80	MGR 90
BASIC USERS →	USER 01	USER 11	USER 21	USER 31	USER 41	USER 51	USER 61	USER 71	USER 81	USER 91
BASIC USERS →	USER 02	USER 12	USER 22	USER 32	USER 42	USER 52	USER 62	USER 72	USER 82	USER 92
BASIC USERS →	USER 03	USER 13	USER 23	USER 33	USER 43	USER 53	USER 63	USER 73	USER 83	USER 93
BASIC USERS →	USER 04	USER 14	USER 24	USER 34	USER 44	USER 54	USER 64	USER 74	USER 84	USER 94
BASIC USERS →	USER 05	USER 15	USER 25	USER 35	USER 45	USER 55	USER 65	USER 75	USER 85	USER 95
BASIC USERS →	USER 06	USER 16	USER 26	USER 36	USER 46	USER 56	USER 66	USER 76	USER 86	USER 96
BASIC USERS →	USER 07	USER 17	USER 27	USER 37	USER 47	USER 57	USER 67	USER 77	USER 87	USER 97
BASIC USERS →	USER 08	USER 18	USER 28	USER 38	USER 48	USER 58	USER 68	USER 78	USER 88	USER 98
BASIC USERS →	USER 09	USER 19	USER 29	USER 39	USER 49	USER 59	USER 69	USER 79	USER 89	USER 99

MASTER CODE

SERVICE CODE 1

SERVICE CODE 2

SERVICE CODE 3

LOCK DESCRIPTION

This lock provides three types of codes: **Master** (can perform ALL functions), **Manager** (can perform SOME programming functions plus entry through the door), and **Basic User** (entry only). In total, there are 104 "locations" inside the lock: One Master Code, 10 Manager Codes, 90 Basic Codes, and three one-time entry "Service Codes". <u>Where</u> the Code is located determines its programming abilities. From the factory, all locations (except for the Master Code) are empty; each location can then be programmed to contain a code to allow users to program and/or unlock the lock to allow entry.

As a visual aid, these code locations are shown in the grid below, with ten "Banks" (columns) of ten "Managers/Basic Users" in the rows (the grid excludes the Master Code and the 3 Service Codes). Each of the 100 squares in the grid is identified by a unique two-digit location (00) through (99). Notice the two digits also specify its Bank (column) and row location in the grid. Also notice that all Managers are in the top row, their locations all ending in a zero (locations 00, 10, 20, 30 and so on through 90). Use the blank grid below as a worksheet for preparing all programming in advance. Store this worksheet in a safe place for future reference.

Ea	ch square re C	presents a lo codes). Each	cation inside location car	the lock (ex hold one co	cluding the N de that can u	laster Code Inlock the lo	and the 3 Sei ck.	rvice		
	BANK 0	BANK 1	BANK 2	BANK 3	BANK 4	BANK 5	BANK 6	BANK 7	BANK 8	BANK 9
MANAGERS	MGR 00	MGR 10	MGR 20	MGR 30	MGR 40	MGR 50	MGR 60	MGR 70	MGR 80	MGR 90
BASIC USERS →	USER 01	USER 11	USER 21	USER 31	USER 41	USER 51	USER 61	USER 71	USER 81	USER 91
BASIC USERS →	USER 02	USER 12	USER 22	USER 32	USER 42	USER 52	USER 62	USER 72	USER 82	USER 92
BASIC USERS →	USER 03	USER 13	USER 23	USER 33	USER 43	USER 53	USER 63	USER 73	USER 83	USER 93
BASIC USERS →	USER 04	USER 14	USER 24	USER 34	USER 44	USER 54	USER 64	USER 74	USER 84	USER 94
BASIC USERS →	USER 05	USER 15	USER 25	USER 35	USER 45	USER 55	USER 65	USER 75	USER 85	USER 95
BASIC USERS →	USER 06	USER 16	USER 26	USER 36	USER 46	USER 56	USER 66	USER 76	USER 86	USER 96
BASIC USERS →	USER 07	USER 17	USER 27	USER 37	USER 47	USER 57	USER 67	USER 77	USER 87	USER 97
BASIC USERS →	USER 08	USER 18	USER 28	USER 38	USER 48	USER 58	USER 68	USER 78	USER 88	USER 98
BASIC USERS →	USER 09	USER 19	USER 29	USER 39	USER 49	USER 59	USER 69	USER 79	USER 89	USER 99

MASTER CODE

SERVICE CODE 1

SERVICE CODE 2

SERVICE CODE 3

LOCK DESCRIPTION

ALARM LOCK LIMITED WARRANTY

ALARM LOCK SYSTEMS, INC. (ALARM LOCK) warrants its products to be free from manufacturing defects in materials and workmanship for twenty four months following the date of manufacture. ALARM LOCK will, within said period, at its option, repair or replace any product failing to operate correctly without charge to the original purchaser or user.

This warranty shall not apply to any equipment, or any part thereof, which has been repaired by others, improperly installed, improperly used, abused, altered, damaged, subjected to acts of God, or on which any serial numbers have been altered, defaced or removed. Seller will not be responsible for any dismantling or reinstallation charges, environmental wear and tear, normal maintenance expenses, or shipping and freight expenses required to return products to ALARM LOCK. Additionally, this warranty shall not cover scratches, abrasions or deterioration due to the use of paints, solvents or other chemicals.

THERE ARE NO WARRANTIES, EXPRESS OR IM-PLIED, WHICH EXTEND BEYOND THE DESCRIPTION ON THE FACE HEREOF. THERE IS NO EXPRESS OR IMPLIED WARRANTY OF MERCHANTABILITY OR A WARRANTY OF FITNESS FOR A PARTICULAR PUR-POSE. ADDITIONALLY, THIS WARRANTY IS IN LIEU OF ALL OTHER OBLIGATIONS OR LIABILITIES ON THE PART OF ALARM LOCK.

Any action for breach of warranty, including but not limited to any implied warranty of merchantability, must be brought within the six months following the end of the warranty period.

IN NO CASE SHALL ALARM LOCK BE LIABLE TO AN-YONE FOR ANY CONSEQUENTIAL OR INCIDENTAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED, EVEN IF THE LOSS OR DAMAGE IS CAUSED BY THE SELLER'S OWN NEGLIGENCE OR FAULT.

In case of defect, contact the security professional who installed and maintains your security system. In order to exercise the warranty, the product must be returned by the security professional, shipping costs prepaid and insured to ALARM LOCK. After repair or replacement, ALARM LOCK assumes the cost of returning products under warranty. ALARM LOCK shall have no obligation under this warranty, or otherwise, if the product has been repaired by others, improperly installed, improperly used, abused, altered, damaged, subjected to accident, nuisance, flood, fire or acts of God, or on which any serial numbers have been altered, defaced or removed. ALARM LOCK will not be responsible for any dismantling, reassembly or reinstallation charges, environmental wear and tear, normal maintenance expenses, or shipping and freight expenses required to return products to ALARM LOCK. Additionally, this warranty shall not cover scratches, abrasions or deterioration due to the use of paints, solvents or other chemicals.

This warranty contains the entire warranty. It is the sole warranty and any prior agreements or representations, whether oral or written, are either merged herein or are expressly cancelled. ALARM LOCK neither assumes, nor authorizes any other person purporting to act on its behalf to modify, to change, or to assume for it, any other warranty or liability concerning its products.

In no event shall ALARM LOCK be liable for an amount in excess of ALARM LOCK's original selling price of the product, for any loss or damage, whether direct, indirect, incidental, consequential, or otherwise arising out of any failure of the product. Seller's warranty, as hereinabove set forth, shall not be enlarged, diminished or affected by and no obligation or liability shall arise or grow out of Seller's rendering of technical advice or service in connection with Buyer's order of the goods furnished hereunder.

ALARM LOCK RECOMMENDS THAT THE ENTIRE SYSTEM BE COMPLETELY TESTED WEEKLY.

Warning: Despite frequent testing, and due to, but not limited to, any or all of the following; criminal tampering, electrical or communications disruption, it is possible for the system to fail to perform as expected. ALARM LOCK does not represent that the product/system may not be compromised or circumvented; or that the product or system will prevent any personal injury or property loss by burglary, robbery, fire or otherwise; nor that the product or system will in all cases provide adequate warning or protection. A properly installed and maintained alarm may only reduce risk of burglary, robbery, fire or otherwise but it is not insurance or a guarantee that these events will not occur. CONSEQUENTLY, SELLER SHALL HAVE NO LIABILITY FOR ANY PERSONAL INJURY, PROPERTY DAMAGE, OR OTHER LOSS BASED ON A CLAIM THE PRODUCT FAILED TO GIVE WARNING. Therefore, the installer should in turn advise the consumer to take any and all precautions for his or her safety including, but not limited to, fleeing the premises and calling police or fire department, in order to mitigate the possibilities of harm and/or damage.

ALARM LOCK is not an insurer of either the property or safety of the user's family or employees, and limits its liability for any loss or damage including incidental or consequential damages to ALARM LOCK's original selling price of the product regardless of the cause of such loss or damage.

Some states do not allow limitations on how long an implied warranty lasts or do not allow the exclusion or limitation of incidental or consequential damages, or differentiate in their treatment of limitations of liability for ordinary or gross negligence, so the above limitations or exclusions may not apply to you. This Warranty gives you specific legal rights and you may also have other rights which vary from state to state.

MODEL DL2700DB & CR (DeadBolt & ClassRoom Models) **PARTS LIST**

Key S Part#		Description	Key	Part #
1a	S6127-26D	Battery Cover	1+8	
1b	S6127-26	Battery Cover	1+8	
1c	S6127-US3	Battery Cover	1+8	
1d	S6127-US5	Battery Cover	1+8	
1e	S6127-26D	Battery Cover	1+8	
2a	S6128-26D	In/Out Lever-Straight		
2b	S6128-26	In/Out Lever-Straight		
2c	S6128-US3	In/Out Lever-Straight		
2d	S6128-US5	In/Out Lever-Straight		
2e	S6128-10B	In/Out Lever-Straight		
2a	S6129-26D	In/Out Lever-Regal		
2b	S6129-26	In/Out Lever-Regal		
2c	S6129-US3	In/Out Lever-Regal		
2d	S6129-US5	In/Out Lever-Regal		
2e	S6129-10B	In/Out Lever-Regal		
3a	S6130-26D	InsideHousingAss'yDB		
3b	S6130-26	InsideHousingAss'yDB		
3c	S6130-US3	InsideHousingAss'yDB		
3d	S6130-US5	InsideHousingAss'yDB		
3e	S6130-10B	InsideHousingAss'yDB		
3a	S6131-26D	InsideHousingAss'yCR		
3b	S6131-26	InsideHousingAss'yCR		
3c	S6131-US3	InsideHousingAss'yCR		
3d	S6131-US5	InsideHousingAss'yCR		
3e	S6131-10B	InsideHousingAss'yCR		

Mounting Screws (4)

		.	,	
4a	S6135-26D	#6-32x3/8", Oval Head	4+6+7	SC476-26D
4b	S6135-26	#6-32x3/8", Oval Head	4+6+7	SC476-26
4c	S6135-US3	#6-32x3/8", Oval Head	4+6+7	SC476-US3
4d	S6135-US5	#6-32x3/8", Oval Head	4+6+7	SC476-US5
4e	S6135-10B	#6-32x3/8", Oval Head	4+6+7	SC476-10B

Mounting Screws (2)

5	SC478	#6-32x3/8", Flat Head	4+5+7	
6	SC136	Inside Mounting Plate		

Inside Mounting Plate Screws (6)

7	SC479	#8-32x1",Flat Hd.,PH,MS	4+5+7	
8a	P5851-26D	#4-40x1/4",Flat Hd.,PH,MS	1+8	
8b	P5851-US3	#4-40x1/4",Flat Hd.,PH,MS	1+8	

Lock Body-DeadBolt (DB)

_					
	9a	S6137-26D	LockBody-DeadBolt-LH	9+12	
	9b	S6137-26	LockBody-DeadBolt-LH	9+12	
	9c	S6137-US3	LockBody-DeadBolt-LH	9+12	
	9d	S6137-US5	LockBody-DeadBolt-LH	9+12	
	9e	S6137-10B	LockBody-DeadBolt-LH	9+12	
	9a	S6141-26D	LockBody-DeadBolt-RH	9+12	
	9b	S6141-26	LockBody-DeadBolt-RH	9+12	
	9c	S6141-US3	LockBody-DeadBolt-RH	9+12	
	9d	S6141-US5	LockBody-DeadBolt-RH	9+12	
	9e	S6141-10B	LockBody-DeadBolt-RH	9+12	



Lock Body-ClassRoom (CR)

US3

US5

26D

26

10B

Key	S Part #	Description	Key
10a	S6138-26D	Lock Body-Deadbolt-LH	10+13
10b	S6138-26	Lock Body-Deadbolt-LH	10+13
10c	S6138-US3	Lock Body-Deadbolt-LH	10+13
10d	S6138-US5	Lock Body-Deadbolt-LH	10+13
10e	S6138-10B	Lock Body-Deadbolt-LH	10+13
10a	S6142-26D	Lock Body-Deadbolt-RH	10+13
10b	S6142-26	Lock Body-Deadbolt-RH	10+13
10c	S6142-US3	Lock Body-Deadbolt-RH	10+13
10d	S6142-US5	Lock Body-Deadbolt-RH	10+13
10e	S6142-10B	Lock Body-Deadbolt-RH	10+13

Key	S Part #	Description	Key
11a	S6123-26D	Outside Housing Ass'y	
11b	S6123-26	Outside Housing Ass'y	
11c	S6123-US3	Outside Housing Ass'y	
11d	S6123-US5	Outside Housing Ass'y	
11e	S6123-10B	Outside Housing Ass'y	
12a	S6139-26D	Strike/Face Plate Kit DB	9+12+14
12b	S6139-26	Strike/Face Plate Kit DB	9+12+14
12c	S6139-US3	Strike/Face Plate Kit DB	9+12+14
12d	S6139-US5	Strike/Face Plate Kit DB	9+12+14
12e	S6139-10B	Strike/Face Plate Kit DB	9+12+14



345 Bayview Avenue, Amityville, New York 11701 For Sales and Repairs 1-800-AL4-LOCK For Technical Service 1-800-645-9440 or visit us at <u>http://tech.napcosecurity.com/</u> Technical Service is for security professionals Publicly traded on NASDAQ Symbol: NSSC © ALARM LOCK 2017

WI2223 02/17

Key	S Part #	Description	Key
13a	S6140-26D	Strike/Face Plate Kit CR	10+13+15
13b	S6140-26	Strike/Face Plate Kit CR	10+13+15
13c	S6140-US3	Strike/Face Plate Kit CR	10+13+15
13d	S6140-US5	Strike/Face Plate Kit CR	10+13+15
13e	S6140-10B	Strike/Face Plate Kit CR	10+13+15
14a	S6133-26D	Mortise Cyl. Clover Cam	
14b	S6133-26	Mortise Cyl. Clover Cam	
14c	S6133-US3	Mortise Cyl. Clover Cam	
14d	S6133-US5	Mortise Cyl. Clover Cam	
14e	S6133-10B	Mortise Cyl. Clover Cam	
15a	S6134-26D	Mortise Cyl. Straight Cam	
15b	S6134-26	Mortise Cyl. Straight Cam	
15c	S6134-US3	Mortise Cyl. Straight Cam	
15d	S6134-US5	Mortise Cyl. Straight Cam	
15e	S6134-10B	Mortise Cyl. Straight Cam	
16	S6132	Battery Pack Assembly	

PROGRAMMING T2 FUNCTIONS

To program desired function, follow procedure in right column (assumes Master Code is programmed first).

FUNCTION	PRESS THESE BUTTONS ON KEYPAD
Pass Time ("Door Unlock")	Press Master Code 💽 4 [Enter between "02" (02) through "20" (20) "20" seconds] then press 1
Enable Groups	Press Master Code 💷 🖸 🚺 💽
Disable Groups	Press Master Code 💷 💷 💷
Disable Users In Bank	Press Master or Manager Code 💷 📧 5
Enable Users in Bank	Press Master or Manager Code 💷 📧 4
Disable / Enable User Number (Toggle)	Press Master or Manager Code Number] [Enter User Number] (wait for beeps and for the lock to re-lock)
Disable All	Press Master or Manager Code 💷 🧐 5 (Reset with Function 944)
Enable All	Press Master or Manager Code 💷 🧐 4
Disable Users Only	Press Master or Manager Code 💷 🧐 5 (Reset with Function 944)

T2 QUICK-REFERENCE GUIDE TO PROGRAMMING CODES AND FUNCTIONS



345 Bayview Avenue Amityville, New York 11701 For Sales and Repairs 1-800-ALA-LOCK For Technical Service 1-800-645-9440

Publicly traded on NASDAQ

Symbol: NSSC

© ALARM LOCK 2017

Fold on Line

QUICK REFERENCE GUIDE TO PROGRAMMING CODES

INSTRUCTIONS: To program desired function, follow procedure in right column.

FUNCTION	PRESS THESE BUTTONS ON KEYPAD		
Restore Factory Default	 Remove the battery pack, and with the batteries disconnected, press any numeric key for 10 seconds and release. Connect batteries andwithin 3 secondspress and hold . After hearing 6 additional beeps, release . 		
(Load original factory settings)	Important: If you do not hear 6 beeps, you must start over at step 1.		
	[Enter Factory or Existing Master Code]		
Change Existing Master Code	[Re-enter New Master Code] [6 beeps = OK].		
	Factory Master Code MUST be re-programmed; allows lock configuration, passage and user management functions.		
	[Enter Master Code] [I] [Enter 2-digit Manager Location _] [I].		
Add/Change Manager Codes (up to 10 Manager Codes allowed)	[Enter new Manager Code] [6 beeps = OK].		
	Allows passage and user management functions.		
Add/Change User Codes	Press Master or Manager Code [I] [Enter 2-digit Location _] [I] [Enter new User Code]		
(up to 90 User Codes allowed)	[6 beeps = OK]		
Deleting Manager & User Codes	Press Master or Manager Code 💷 [Enter Bank Number] [Enter User Number]		
Code Location Function	Press Master or Manager Code III 6 III [Enter Code to be located]		
Next Free CodeAddress Locator	Press Master or Manager Code II I II II IResponds with Bank # and User #]		
Service Code 1	Press Master or Manager Code 💷 🕄 💽 1 💷 [Enter new Service Code]		
Service Code 2	Press Master or Manager Code 💷 🛐 💽 😰 [Enter new Service Code]		
Service Code 3	Press Master or Manager Code 💷 🛐 💽 🕄 [Enter new Service Code]		
Clear Service Codes	Press Master or Manager Code 💷 🛐 💽 💽		
Enable Passage Mode	Press Master or Manager Code 💷 🕘		
Disable Passage Mode	Press Master or Manager Code 💶 💿 💷		