



345 Bayview Avenue, Amityville, New York 11701
 For Sales and Repairs 1-800-ALARM LOCK
 For Technical Service 1-800-845-8440
 or visit us at <http://tech.napcosecurity.com/>
 (Note: Technical Service is for security professionals only)
 Publicly traded on NASDAQ Symbol: NSSC
 © ALARM LOCK 2025

Trilogy T2 DL2700 & TL2700

Programming Instructions

Mortise, Cylindrical & Exit Trim Locks

OI209D.aLF 3/25

CONGRATULATIONS!

Your new Alarm Lock Trilogy electronic digital lock is a rugged entry lock of advanced design with several programmable features.

The 2700 series features two models that are identical in operation but with different keypad types: The traditional DL2700 with a standard keypad with pressable buttons and the TL2700 with a flat touch-sensitive touchpad that illuminates when touched.

The lock provides three types of codes: **Master** (can perform ALL functions), **Manager** (can perform MOST functions plus entry through the door), and **Basic User** (entry only). The lock includes 100 codes (consisting of Manager and Basic), plus three one-time entry "Service Codes". As you will see in the following pages, the codes are organized in a grid -- ten banks (columns) of ten codes (rows).

Take the time to read through this guide to familiarize yourself with its features, operations and programming steps.

Features (both models)

- 1 Master Code (all functions including entry)
- 10 Manager Codes (perform MOST programming functions plus entry)
- 90 Basic Codes (entry only)
- 3 Service Codes ("one-time entry" codes)
- Two User Disable Modes:
 - All Codes Disabled Except Master Code
 - All Codes in a Bank Disabled Except Manager Codes
- 30-Second Keypad Anti-Tamper Lockout: (Keypad Lockout After 3 Unsuccessful Code Entries)
- Programmable Relay Functions: (Relay may be keypad-programmed to energize on any keypress (0-9) or on unlock).

Model TL2700 Touchpad Features

Identical to the DL2700 above, but includes:

- Touch-sensitive instant-on back-lit screen
- Extremely resistant to dirt, water and most chemicals
- Designed for effortless, long-lasting operation



DL2700
(Cylindrical with Standard Keys)

TL2700
(Cylindrical with Touch keypad)

QUICK LOOKUP

Wiring	2
Quick Start	2-3
Testing Codes	3
Manager & User Location Worksheet	4
Manager & User Location Example	5
Programming Worksheet: Functions	6
Change Existing Master Code	7
Add/Change Manager Codes	7
Add/Change User Codes	7
Deleting Codes	7
Disable/Enable Users	7
Disable/Enable All	8
Code Location Function	8
Next Free Code Address Locator	8
Add/Delete Service Codes	9
Enable/Disable Passage Mode	9
Pass Time ("Door Unlock")	9
Disable/Enable Groups	9
Disable/Enable Users in Bank	10
Keypress Sound Options	10
AUX Relay Functions	10
Lock Identifier	10
Enable / Disable Emergency Chirp	11
Remote Switch Input Wires Toggle Passage Mode	11
Audible and LED Indications	11
Battery Replacement	12
Erase All Programming	12
Extra Manager & User Location Worksheets ...	13-15
Limited Warranty	16

Wiring

See the Installation Instructions for more information.

Batteries:

Use only 1.5 volt Duracell Alkaline size-AA batteries.

External Power:

An external 7.5 VDC Power Source, capable of at least 100mA, must be used for operation without batteries in the lock. Use an external UL-Listed power supply provided with backup battery power and current limiting protection that is approved for the application.

BLACK = Negative, RED = Positive.

Aux Relay:

Aux Relay allows up to 300mA @ 60VDC Maximum. See page 10 for programming options for the Relay ("AUX Relay Functions").
BLUE = Common, YELLOW = N/O, GREEN = N/C.



Remote Switch Input (2 White Wires)

A remote momentary switch can be wired to allow access through the door when activated. Wire a normally open push button switch to the two white wires (depress (close) the push button for one second to unlock the unit).

Quick Start

First Time Start Up










Failure to follow this exact procedure can result in erratic lock behavior. **Note:** When entering key sequences, *do not pause more than 5 seconds between key entries or you must start again.*

1. With batteries disconnected, press/hold down a numeric key for 10 seconds and release.
2. Connect batteries and within 3 seconds press/hold down . After hearing 6 beeps, release . Wait 5 seconds for lock to re-lock (listen for 1 beep with a red LED). The lock is now ready for programming.
3. The Factory Master Code **MUST** be changed as described in the next section.







Change Factory Master Code

The Master Code is your "secret" code entered at the keypad that allows you to change ALL programming functions and options. Because all locks are manufactured with the *same* Master Code, this "factory" Master Code is not "secret", and therefore **MUST** be changed to ensure security. Your Master Code may contain between 3-6 digits but we recommend using 5 - 6 digits. **Note:** The number of digits in your new Master Code will determine the number of digits required for ALL subsequent codes added.

We recommend reading the steps below before performing them.

1. Enter the factory Master Code:     . A beep will sound and the lock will open.
2. Within 5 seconds, enter   .
3. Within 5 seconds, enter your new Master Code and press .
4. Re-enter your new Master Code. Listen for a 6-beep acknowledgement (with a red LED), then wait 5 seconds for lock to re-lock.
5. **Test your new Master Code:** Enter your new Master Code and listen for a beep and for the lock to unlock.

If you wish, write your new Master Code in the spaces below:

        _____  _____
Your new Master Code (Repeat)

Enter "Manager" Codes

Before proceeding, we recommend reading the description of the grid on page 4. Basic Codes only allow access through the door. Manager Codes allow access and ALSO have the ability to program and delete Basic Codes within that Manager's Bank (column) *and also for all higher Banks until the next programmed Manager Code appears in a higher Bank.*


The lock can hold up to 10 Manager Codes, one for each Bank (Manager Codes are located in locations (00), (10), (20), (30), (40), (50), (60), (70), (80), (90)), all located at the top row of the grid. **Note:** Only the Master Code can add or delete a Manager Code.


Continued

* After the number of digits is selected, it cannot be changed unless all programming is erased and the Factory Default settings are re-loaded using the "Erase All Programming" procedure found on page 12.

Quick Start (cont'd)

Before adding Manager Codes, read the steps below before performing them.



1. Enter your previously programmed new Master Code.
2. Enter  followed by a selected Manager location (i.e., 00, 10, 20, 30, 40, 50, 60, 70, 80, or 90).
3. Enter a new Manager Code *using the same number of digits as your new Master Code*. A 6-beep acknowledgement (with a red LED) will sound. Wait 5 seconds for lock to re-lock (if the lock remains unlocked, repeat from step 2, otherwise restart from step 1 for each new Manager Code). If you wish, write a new Manager Code in the space below:



Enter "Basic" Codes

Basic Codes only allow entry through the door. Duplicate codes are not allowed. Enter Basic Codes in any order you wish.

We recommend that you read the steps below before performing them.




1. Enter your previously programmed new Master Code or associated Manager Code.
2. Enter  [enter a 2-digit location number] .
3. Enter a new Basic Code *using the same number of digits as your new Master Code*. A six-beep acknowledgement (with a red LED) will sound. Wait 5 seconds for lock to re-lock (if lock remains unlocked, repeat from step 2; otherwise restart from step 1).

Example: Add a Basic Code of "22222" in location "01", enter:




[Master or associated Manager Code]  0 1  2 2 2 2 2

Delete a Code

The Master Code can be *changed* but cannot be *deleted*. Manager Codes can only be deleted using the Master Code. If the location of the code is unknown, use the *Code Location Function* on page 8.


1. Enter the Master Code or associated Manager Code.
2. Enter  [enter the 2-digit location number]  * . A six-beep acknowledgement (with a red LED) will sound. Wait 5 seconds for lock to re-lock (upon re-lock the code will be deleted). If lock remains unlocked, repeat from step 2; otherwise restart from step 1 for each code you want to delete.

Example: Delete a Basic Code in location 47, enter:

[Master or associated Manager Code]  4 7  * 

Testing Codes

VALID CODE - The Green LED will flash (with 1 beep) after a valid code is entered. The lock will unlock immediately and remain unlocked for about 5 seconds (this "unlocked" time is the "Pass Time"). To make the Pass Time longer or shorter, use the Pass Time Function on page 9. **Note:** While the lever or knob may be rotated at any time, the latch will not be engaged to unlock the door unless a valid code is entered at the keypad.

INVALID CODE - The Red LED will flash 5 times (with 5 beeps) after an invalid code is entered. (To quickly clear a mis-keyed or invalid code, enter  and immediately re-enter the correct code).

KEYPAD ANTI-TAMPER LOCKOUT - If 3 invalid codes are entered in succession, the lock will enter Anti-Tamper mode by turning off for approximately 30 seconds to prevent tampering. The lock will emit 2 beeps with a Red LED flash warning at the end of the Anti-Tamper mode period. The lock will exit Anti-Tamper mode immediately upon activation of the Remote Switch Input (white wires). **Note:** The lock will go into Anti-Tamper mode after 3 unsuccessful code entries *even if entered by different users and spaced apart in time*. Therefore, the lock may "appear" to go into Anti-Tamper mode lockout *even after the entry of just one invalid code*.

Manager & Basic User Location Worksheet

This lock provides three types of codes: **Master** (can perform ALL functions), **Manager** (can perform SOME programming functions plus entry through the door), and **Basic User** (entry only). In total, there are 104 "locations" inside the lock: One Master Code, 10 Manager Codes, 90 Basic Codes, and three one-time entry "Service Codes". *Where the Code is located determines its programming abilities.* From the factory, all locations (except for the Master Code) are empty; each location can then be programmed to contain a code to allow users to program and/or unlock the lock to allow entry.

As a visual aid, these code locations are shown in the grid below, with ten "Banks" (columns) of ten "Managers/Basic Users" in the rows (the grid excludes the Master Code and the 3 Service Codes). Each of the 100 squares in the grid is identified by a unique two-digit location (00) through (99). Notice the two digits also specify its Bank (column) and row location in the grid. Also notice that all Managers are in the top row, their locations all ending in a zero (locations 00, 10, 20, 30 and so on through 90). Use the blank grid below as a worksheet for preparing all programming in advance. Store this worksheet in a safe place for future reference.

Each square represents a location inside the lock (excluding the Master Code and the 3 Service Codes). Each location can hold one code that can unlock the lock.

	BANK 0	BANK 1	BANK 2	BANK 3	BANK 4	BANK 5	BANK 6	BANK 7	BANK 8	BANK 9
MANAGERS →	MGR 00 -----	MGR 10 -----	MGR 20 -----	MGR 30 -----	MGR 40 -----	MGR 50 -----	MGR 60 -----	MGR 70 -----	MGR 80 -----	MGR 90 -----
BASIC USERS →	USER 01 -----	USER 11 -----	USER 21 -----	USER 31 -----	USER 41 -----	USER 51 -----	USER 61 -----	USER 71 -----	USER 81 -----	USER 91 -----
BASIC USERS →	USER 02 -----	USER 12 -----	USER 22 -----	USER 32 -----	USER 42 -----	USER 52 -----	USER 62 -----	USER 72 -----	USER 82 -----	USER 92 -----
BASIC USERS →	USER 03 -----	USER 13 -----	USER 23 -----	USER 33 -----	USER 43 -----	USER 53 -----	USER 63 -----	USER 73 -----	USER 83 -----	USER 93 -----
BASIC USERS →	USER 04 -----	USER 14 -----	USER 24 -----	USER 34 -----	USER 44 -----	USER 54 -----	USER 64 -----	USER 74 -----	USER 84 -----	USER 94 -----
BASIC USERS →	USER 05 -----	USER 15 -----	USER 25 -----	USER 35 -----	USER 45 -----	USER 55 -----	USER 65 -----	USER 75 -----	USER 85 -----	USER 95 -----
BASIC USERS →	USER 06 -----	USER 16 -----	USER 26 -----	USER 36 -----	USER 46 -----	USER 56 -----	USER 66 -----	USER 76 -----	USER 86 -----	USER 96 -----
BASIC USERS →	USER 07 -----	USER 17 -----	USER 27 -----	USER 37 -----	USER 47 -----	USER 57 -----	USER 67 -----	USER 77 -----	USER 87 -----	USER 97 -----
BASIC USERS →	USER 08 -----	USER 18 -----	USER 28 -----	USER 38 -----	USER 48 -----	USER 58 -----	USER 68 -----	USER 78 -----	USER 88 -----	USER 98 -----
BASIC USERS →	USER 09 -----	USER 19 -----	USER 29 -----	USER 39 -----	USER 49 -----	USER 59 -----	USER 69 -----	USER 79 -----	USER 89 -----	USER 99 -----

MASTER CODE

SERVICE CODE 1

SERVICE CODE 2

SERVICE CODE 3

Manager & Basic User Location Example

Basic Codes only allow access through the door. Manager Codes allow access and ALSO have the ability to program and delete Basic Codes within that Manager's Bank (column) *and also for all higher Banks until the next programmed Manager Code appears in a higher Bank.*

The lock can hold up to 10 Manager Codes, one for each Bank (locations (00), (10), (20), (30), (40), (50), (60), (70), (80), (90)), all located at the top row of the grid below. **Note:** Only the Master Code can add or delete a Manager Code.

In the example grid below, if Manager Codes are programmed for locations (00) and (60), then the Manager in location (00) has control of all gray-shaded locations (00-09, 11-19, 21-29, 31-39, 41-49, and 51-59). The Manager in location (60) then has control over the black-shaded locations (61-69, 71-79, 81-89, and 91-99).

Note: If you wish to grant any Manager the ability to program any User, use the "Disable Groups" Function on page 9 (enter the Master Code, then enter     ).

	Manager Code Programmed here						Manager Code Programmed here			
	(BANK 0)	(BANK 1)	(BANK 2)	(BANK 3)	(BANK 4)	(BANK 5)	(BANK 6)	(BANK 7)	(BANK 8)	(BANK 9)
MANAGERS →	MGR 00	MGR 10 (BLANK)	MGR 20 (BLANK)	MGR 30 (BLANK)	MGR 40 (BLANK)	MGR 50 (BLANK)	MGR 60	MGR 70 (BLANK)	MGR 80 (BLANK)	MGR 90 (BLANK)
BASIC USERS →	USER 01	USER 11	USER 21	USER 31	USER 41	USER 51	USER 61	USER 71	USER 81	USER 91
BASIC USERS →	USER 02	USER 12	USER 22	USER 32	USER 42	USER 52	USER 62	USER 72	USER 82	USER 92
BASIC USERS →	USER 03	USER 13	USER 23	USER 33	USER 43	USER 53	USER 63	USER 73	USER 83	USER 93
BASIC USERS →	USER 04	USER 14	USER 24	USER 34	USER 44	USER 54	USER 64	USER 74	USER 84	USER 94
BASIC USERS →	USER 05	USER 15	USER 25	USER 35	USER 45	USER 55	USER 65	USER 75	USER 85	USER 95
BASIC USERS →	USER 06	USER 16	USER 26	USER 36	USER 46	USER 56	USER 66	USER 76	USER 86	USER 96
BASIC USERS →	USER 07	USER 17	USER 27	USER 37	USER 47	USER 57	USER 67	USER 77	USER 87	USER 97
BASIC USERS →	USER 08	USER 18	USER 28	USER 38	USER 48	USER 58	USER 68	USER 78	USER 88	USER 98
BASIC USERS →	USER 09	USER 19	USER 29	USER 39	USER 49	USER 59	USER 69	USER 79	USER 89	USER 99

Manager Location Example

Programming Worksheet: Functions


The "factory" Master Code (1-2-3-4-5) must first be changed to a new Master Code before any other programming can take place. All new codes must have the same number of digits as the new Master Code. Choose new codes and write them in spaces provided below (in pencil) before programming the lock. 6 beeps will usually be heard after a valid entry.

FUNCTION	KEYPAD ENTRIES
Change Existing Master Code	[Enter Factory or Existing Master Code] <input type="text" value="1"/> <input type="text" value="2"/> [Enter New Master Code _____] <input type="text" value="5"/> [Re-enter New Master Code _____] [6 beeps = OK]
Add/Change Manager Codes (up to 10)	[Enter Master Code] <input type="text" value="1"/> [Enter 2-digit Manager Location ____] <input type="text" value="5"/> [Enter new Manager Code _____] [6 beeps = OK]
Add/Change Basic Codes (up to 90)	Enter Master or Manager Code <input type="text" value="1"/> [Enter 2-digit Location ____] <input type="text" value="5"/> [Enter new Basic Code _____] [6 beeps = OK]
Deleting Manager & Basic Codes	Enter Master or Manager Code <input type="text" value="1"/> [Enter Bank Number] [Enter User Number] <input type="text" value="5"/> <input type="text" value="0"/>
Disable / Enable User Number (Toggle)	Enter Master or Manager Code <input type="text" value="1"/> [Enter Bank Number] [Enter User Number] <input type="text" value="5"/> (wait)
Disable All	Enter Master or Manager Code <input type="text" value="1"/> <input type="text" value="9"/> <input type="text" value="5"/> <input type="text" value="5"/> (Reset with "Enable All" Function 944)
Enable All	Enter Master or Manager Code <input type="text" value="1"/> <input type="text" value="9"/> <input type="text" value="4"/> <input type="text" value="4"/>
Disable Users Only	Enter Master or Manager Code <input type="text" value="1"/> <input type="text" value="9"/> <input type="text" value="5"/> <input type="text" value="0"/> (Reset with "Enable All" Function 944)
Code Location Function	Enter Master or Manager Code <input type="text" value="1"/> <input type="text" value="6"/> [Enter code to be located]
Next Free Code--Address Locator	Enter Master or Manager Code <input type="text" value="1"/> <input type="text" value="7"/> [Responds with Bank # and User #]
Service Code 1	Enter Master or Manager Code <input type="text" value="1"/> <input type="text" value="3"/> <input type="text" value="0"/> <input type="text" value="1"/> [Enter new Service Code _____]
Service Code 2	Enter Master or Manager Code <input type="text" value="1"/> <input type="text" value="3"/> <input type="text" value="0"/> <input type="text" value="2"/> [Enter new Service Code _____]
Service Code 3	Enter Master or Manager Code <input type="text" value="1"/> <input type="text" value="3"/> <input type="text" value="0"/> <input type="text" value="3"/> [Enter new Service Code _____]
Clear Service Codes	Enter Master or Manager Code <input type="text" value="1"/> <input type="text" value="3"/> <input type="text" value="0"/> <input type="text" value="0"/>
Enable Passage Mode	Enter Master or Manager Code <input type="text" value="1"/> <input type="text" value="4"/>
Disable Passage Mode	Enter Master or Manager Code <input type="text" value="1"/> <input type="text" value="5"/>
Pass Time ("Door Unlock")	Enter Master Code <input type="text" value="1"/> <input type="text" value="4"/> [Enter "02" - "20" seconds] <input type="text" value="5"/>
Enable Groups	Enter Master Code <input type="text" value="1"/> <input type="text" value="2"/> <input type="text" value="1"/> <input type="text" value="0"/>
Disable Groups	Enter Master Code <input type="text" value="1"/> <input type="text" value="2"/> <input type="text" value="1"/> <input type="text" value="1"/>
Disable Users In Bank	Enter Master or Manager Code <input type="text" value="1"/> <input type="text" value="8"/> <input type="text" value="5"/> [Enter Bank Number (0-9)] <input type="text" value="5"/>
Enable Users in Bank	Enter Master or Manager Code <input type="text" value="1"/> <input type="text" value="8"/> <input type="text" value="4"/> [Enter Bank Number (0-9)] <input type="text" value="5"/>
High Freq KP Feedback + LED	Enter Master Code <input type="text" value="1"/> <input type="text" value="2"/> <input type="text" value="2"/> <input type="text" value="0"/>
Low Freq KP Feedback + LED	Enter Master Code <input type="text" value="1"/> <input type="text" value="2"/> <input type="text" value="2"/> <input type="text" value="1"/> (With Mortise locks: Keypress "clicks" and entry/error "beeps")
Click! KP Feedback + LED	Enter Master Code <input type="text" value="1"/> <input type="text" value="2"/> <input type="text" value="2"/> <input type="text" value="2"/> (With Mortise locks: Keypress "clicks" and entry/error silent)
LED Only ("library mode")	Enter Master Code <input type="text" value="1"/> <input type="text" value="2"/> <input type="text" value="2"/> <input type="text" value="3"/> All lock models completely silent ("library mode")
Chirp on Emergency	Enter Master Code <input type="text" value="1"/> <input type="text" value="2"/> <input type="text" value="2"/> <input type="text" value="4"/> ("LD" Lock models with Emergency functions only)
No Chirp on Emergency	Enter Master Code <input type="text" value="1"/> <input type="text" value="2"/> <input type="text" value="2"/> <input type="text" value="5"/> ("LD" Lock models with Emergency functions only)
Remote Switch Input Default (see page 2)	Enter Master Code <input type="text" value="1"/> <input type="text" value="2"/> <input type="text" value="3"/> <input type="text" value="0"/> (2 white wires operate normal remote release)
Remote Switch Input Toggle Passage	Enter Master Code <input type="text" value="1"/> <input type="text" value="2"/> <input type="text" value="3"/> <input type="text" value="1"/> (Short beep = passage entry; long beep = passage exit)
Disable AUX Relay Function	Enter Master Code <input type="text" value="1"/> <input type="text" value="2"/> <input type="text" value="0"/> <input type="text" value="0"/>
AUX Relay on any First Keypress (0-9)	Enter Master Code <input type="text" value="1"/> <input type="text" value="2"/> <input type="text" value="0"/> <input type="text" value="1"/>
AUX Relay When Unlocked	Enter Master Code <input type="text" value="1"/> <input type="text" value="2"/> <input type="text" value="0"/> <input type="text" value="2"/>
Lock Identifier	[Any Digit] [Any Digit] <input type="text" value="*"/> [Listen for musical tones]




Programming Functions


Change Existing Master Code*

For new locks, follow the "Quick Start" on page 2. The "Factory" Master Code MUST be changed. The Master Code allows lock configuration, passage through the door and user management functions.




Add/Change Manager Codes [] [0 icon]

Follow the "Quick Start" on pages 2-3. **Note:** You can also add/change the Manager Code in location 00 by entering the Master Code,    then the new Manager Code. Allows passage through the door and user management functions.




Add / Change Basic User Codes [] []

Follow the "Quick Start" on page 3.




Deleting Manager & Basic User Codes [] []

Follow the "Quick Start" on page 3.



Disable / Enable Users (Toggle)

Enter the Master Code to disable / enable any Manager or Basic User, or enter a Manager Code to disable any Basic User within the Manager's Bank.



* After the number of digits is selected, it cannot be changed unless all programming is erased and the factory default settings are re-loaded (i.e., power must be removed and re-applied as per the "Erase All Programming" procedure found on page 12.

** Required only if the unit is locked.






Programming Functions (cont'd)






Enable / Disable All






Disable All: If Master Code is used, disables all 100 Basic User / Manager Codes and clears all 3 Service Codes. If a Manager Code is used, disables all Users (even across multiple Banks) under that Manager.

Disable Users Only: If Master Code is used, disables all 90 Basic Users and clears all 3 Service Codes, while Managers remain active. If a Manager Code is used, disables all Users (even across multiple banks) under that Manager.

Enable All: If Master Code is used, re-enables all 100 Basic User / Manager Codes (Service Codes must be re-programmed). If a Manager Code is used, re-enables all Basic Users (even across multiple Banks) under that Manager. **Note:** Managers cannot disable themselves. Use Function 944 to restore Functions 955 and 950. In addition, if codes are disabled using Function 955 or 950, and a new code is subsequently added (or an existing code changed), the new (or changed) code will automatically become enabled.




Disable All [_____]     
Master/Manager Code**

Disable Users Only [_____]     
Master/Manager Code**

Enable All [_____]     
Master/Manager Code**

Code Location Function

Be sure to record all code locations in the blank worksheet (page 4; also pages 13, 14 and 15) for future reference. Use this function to find an unknown code location. The lock will identify the Bank (0-9) and User (0-9) by beeping and flashing the GREEN LED 0 to 9 times as described below. **Note: When the Bank and/or User numbers are zero, the GREEN LED will not flash and the sounder will not beep.**

[_____]    [_____]
Master/Manager Code** Code 2 - 6 digits




If the code entered is recognized, the following sequence will occur:

1. At the start of the Code Location sequence, the lock will flash both the GREEN and RED LEDs and will emit a low tone.
2. The lock will identify the **Bank** number by flashing the GREEN LED and beeping the sounder from 0 -9 times.
3. To signify the end of the Bank number ID sequence, both the GREEN and RED LEDs will flash with a low tone.
4. The lock will identify the **User** number by flashing the GREEN LED and beeping the sounder from 0-9 times.
5. To signify the end of the Code Location function, both the GREEN and RED LEDs will flash with a low tone.

Note: If the code is not recognized, the lock will sound 5 beeps with a RED LED.

Next Free Code Address Locator

Using the same method of beeps and flashes used in the Code Location Function, and dependent on the Master or Managers Code entered, the lock will report the next available address for code programming.

[_____]   
Master/Manager Code**




Report Sequence






Note: No LED flashes/sounder beeps represent the number zero.






1. At the start of this "next available address" locator function, both the GREEN and RED LEDs will flash with a low tone.
2. The lock will identify the **Bank** number by flashing the GREEN LED and beeping the sounder from 0 - 9 times.
3. To signify the end of the Bank number ID sequence, both the GREEN and RED LEDs will flash with a low tone.
4. The lock will identify the **User** number by flashing the GREEN LED and beeping the sounder from 0- 9 times.
5. To signify the end of this function, both the GREEN and RED LEDs will flash with a low tone. If no free address is found, the lock will emit a programming error tone sequence.






Programming Functions (cont'd)






Add/Delete Service Codes

Service Codes are "one-time-only codes"; after entering a Service Code into the keypad and the lock unlocks, that Service Code is deleted. If you wish, you can use the same Service Code up to 3 times by programming all three Service Codes with the same code sequence. **Note:** Service Codes are lost if power is removed. To delete a single Service Code, enter , enter Service Code number (301, 302 or 303), then enter  .

Service Code 1 [_____]      [_____]
Master/Manager Code** New Service Code




Service Code 2 [_____]      [_____]
Master/Manager Code** New Service Code




Service Code 3 [_____]      [_____]
Master/Manager Code** New Service Code

Delete All Service Codes [_____]     
Master/Manager Code**

Enable/Disable Passage Mode




Allows passage without the need to enter a Code into the keypad.

Enable Passage Mode [_____]    ("Unlocked")
Master or Manager Code**

Disable Passage Mode [_____]    ("Normal Operation")
Master or Manager Code**

Pass Time ("Door Unlock")






The Pass Time is the time the lock stays unlocked after a valid code entry. Use this function to change the Pass Time from 02 to 20 seconds (default is 5 seconds). **Note:** The Pass Time will also determine the amount of time allowed between keypresses during programming.






Pass Time [_____]   [____] 
Master Code** Pass Time
(02 - 20 seconds)

Disable/Enable Groups

Disable Groups: All Managers can program all codes, regardless of Bank.

Enable Groups: (Factory default) Managers restricted to controlling only those codes within their own Bank (column), and all following Banks until another Manager appears in a higher Bank. Codes in Banks outside of that Manager's Bank cannot be programmed.

Disable Groups [_____]     
Master Code**





Enable Groups [_____]     
Master Code**





** Required only if the unit is locked.

Programming Functions (cont'd)

Disable/Enable Users in Bank

Enter Bank number (0-9) to enable or disable all of the codes in a Bank (column). Entering a disabled code results in an accented five beep error tone (indicating the code is valid but disabled).






Disable Users in Bank [_____]    [_] 
Master/Manager Code** Bank Number






Enable Users in Bank [_____]    [_] 
Master/Manager Code** Bank Number






Keypress Sound Options






The lock is capable of emitting 1 of 4 possible keypress sounds:

- **High Frequency Keypress Feedback + LED**
- **Low Frequency Keypress Feedback + LED** (with Mortise locks: Keypress "clicks" and entry/error normal "beeps")
- **"Click!" Keypress Feedback + LED** (with Mortise locks: Keypress "clicks" and entry/error silent)
- **LED Only:** All lock models completely silent ("library mode")

High Freq KP Keypress Sound + LED (Default) [_____]     
Master Code**

Low Freq KP Keypress Sound + LED (Mortise: Keypress "clicks" and entry/error normal "beeps") [_____]     
Master Code**






Click! KP Keypress Sound + LED (Mortise: Keypress "clicks" and entry/error silent) [_____]     
Master Code**





LED Only All lock models completely silent ("library mode") [_____]     
Master Code**

AUX Relay Functions


Program the functions below to activate the Auxiliary Relay on any numeric keypress (Function 201), or when the unit is unlocked (Function 202). In either case the Aux Relay will be active for the duration programmed in Pass Time. See page 2 for information regarding the wiring of AUX leads.


Disable AUX Relay Function [_____]     
Master Code**

AUX Relay on Any First Keypress (0-9) [_____]     
Master Code**

AUX Relay When Unlocked [_____]     
Master Code**

Lock Identifier






To aid in distinguishing your lock model from earlier Alarm Lock versions, your lock model will respond to any two digits plus the  key by (1) lighting the green LED and (2) playing a musical scale of 8 notes.






Lock Identifier [_] [_] 
(Any Two Digits)

Programming Functions (cont'd)

Enable / Disable Emergency Chirp






For lock models with Emergency Lockdown functions only, the lock can be made to sound a chirp when an Emergency command is in effect.






Chirp on Emergency [_____]     
Master Code**

No Chirp on Emergency [_____]     
Master Code**

Remote Switch Input Wires Toggle Passage Mode

The two white Remote Switch Input wires can be programmed to Toggle Passage Mode. To revert back to the default Remote Switch Input operation, use Function 230.

Default Remote Switch Input Operation [_____]     
Master Code**

Remote Switch Input Wires Toggle Passage [_____]     
Master Code**

Audible and LED Indications

When a key is entered, a beep will sound and a Red LED will flash. Other indications are:

- **Access Granted:** 1 beep and a Green LED flash. (When Pass Time ends, the unit locks with a beep and a Red LED flash).
- **Invalid Code Entered:** 5 beeps and 5 Red LED flashes.
- **Disabled Code Entered:** 5 beeps (with extended first beep) and 5 Red LED flashes.
- **New Code Accepted:** 6 beeps and 6 Red LED flashes.
- **Programming Error:** 2 sets of 5 beeps and 5 Red LED flashes.
- **Return from Anti Tamper Lockout:** 2 beeps with a Red LED flash.
- **Low Battery:** High/Low sounder with flashing Red LED for 5 seconds (see next page to replace batteries).

Note: Keypress tones may be disabled using the      command (see Keypress Sound Options, page 10).

Battery Replacement

When the batteries are weak and a key is entered, the lock will alert you by flashing the RED LED accompanied by a high/low sounder. The lock uses five AA-size 1.5 volt alkaline batteries; although the lock will function with weak batteries, be sure to replace them with fresh batteries as soon as possible.



1. Remove the screw at the rear of the lock housing and remove cover.
2. Remove battery pack and replace all 5 batteries.
3. Replace battery pack. Do not touch any keys for 10 seconds.

If you do not hear any beeps or if you hear 3 beeps (one per second), the previous lock programming is retained and the unit is ready for use.


4. Replace cover and tighten the cover screw to secure.

Erase All Programming--DL2700 (With Keypad Buttons)

Restore Factory Default (original settings that were set at the factory will be loaded).

1. Remove the battery pack, and with the batteries disconnected, press/hold down any numeric key for 10 seconds and release.
2. Connect the batteries and--within 3 seconds--press/hold down . After hearing 6 additional beeps, release .



The lock is now clear of all programmed data and is now ready to accept new programming. **Important:** If you do not hear these 6 beeps, you must start over at step 1.


 Failure to follow this exact procedure can result in erratic lock behavior.

Erase All Programming--TL2700 (With Touch Keypad)

Restore Factory Default (original settings that were set at the factory will be loaded).

- **Important:** Read the steps before performing them.

1. Remove and disconnect the battery pack (if equipped; remove all external power).
2. Touch/hold the number  for 3 to 5 seconds then release. **Wait at least 15 seconds before proceeding.**
3. Connect the battery and quickly touch/hold .

- **Important:** Upon power-up, the lock will sound 3 beeps; you **MUST** touch/hold  before the 3rd beep.
4. A series of 6 rapid beeps signifies that the lock has been reset. The lock is now clear of all programmed data and is ready to accept new programming. **Important:** If you do not hear the 6 rapid beeps, you must start over at step 1.

Reminder: Prior to any other programming commands, you must first perform the "Change Factory Master Code" steps located on page 2.

 Failure to follow this exact procedure can result in erratic lock behavior.

Manager & Basic User Location Worksheet

This lock provides three types of codes: **Master** (can perform ALL functions), **Manager** (can perform SOME programming functions plus entry through the door), and **Basic User** (entry only). In total, there are 104 "locations" inside the lock: One Master Code, 10 Manager Codes, 90 Basic Codes, and three one-time entry "Service Codes". *Where the Code is located determines its programming abilities.* From the factory, all locations (except for the Master Code) are empty; each location can then be programmed to contain a code to allow users to program and/or unlock the lock to allow entry.

As a visual aid, these code locations are shown in the grid below, with ten "Banks" (columns) of ten "Managers/Basic Users" in the rows (the grid excludes the Master Code and the 3 Service Codes). Each of the 100 squares in the grid is identified by a unique two-digit location (00) through (99). Notice the two digits also specify its Bank (column) and row location in the grid. Also notice that all Managers are in the top row, their locations all ending in a zero (locations 00, 10, 20, 30 and so on through 90). Use the blank grid below as a worksheet for preparing all programming in advance. Store this worksheet in a safe place for future reference.

Each square represents a location inside the lock (excluding the Master Code and the 3 Service Codes). Each location can hold one code that can unlock the lock.

	BANK 0	BANK 1	BANK 2	BANK 3	BANK 4	BANK 5	BANK 6	BANK 7	BANK 8	BANK 9
MANAGERS →	MGR 00 -----	MGR 10 -----	MGR 20 -----	MGR 30 -----	MGR 40 -----	MGR 50 -----	MGR 60 -----	MGR 70 -----	MGR 80 -----	MGR 90 -----
BASIC USERS →	USER 01 -----	USER 11 -----	USER 21 -----	USER 31 -----	USER 41 -----	USER 51 -----	USER 61 -----	USER 71 -----	USER 81 -----	USER 91 -----
BASIC USERS →	USER 02 -----	USER 12 -----	USER 22 -----	USER 32 -----	USER 42 -----	USER 52 -----	USER 62 -----	USER 72 -----	USER 82 -----	USER 92 -----
BASIC USERS →	USER 03 -----	USER 13 -----	USER 23 -----	USER 33 -----	USER 43 -----	USER 53 -----	USER 63 -----	USER 73 -----	USER 83 -----	USER 93 -----
BASIC USERS →	USER 04 -----	USER 14 -----	USER 24 -----	USER 34 -----	USER 44 -----	USER 54 -----	USER 64 -----	USER 74 -----	USER 84 -----	USER 94 -----
BASIC USERS →	USER 05 -----	USER 15 -----	USER 25 -----	USER 35 -----	USER 45 -----	USER 55 -----	USER 65 -----	USER 75 -----	USER 85 -----	USER 95 -----
BASIC USERS →	USER 06 -----	USER 16 -----	USER 26 -----	USER 36 -----	USER 46 -----	USER 56 -----	USER 66 -----	USER 76 -----	USER 86 -----	USER 96 -----
BASIC USERS →	USER 07 -----	USER 17 -----	USER 27 -----	USER 37 -----	USER 47 -----	USER 57 -----	USER 67 -----	USER 77 -----	USER 87 -----	USER 97 -----
BASIC USERS →	USER 08 -----	USER 18 -----	USER 28 -----	USER 38 -----	USER 48 -----	USER 58 -----	USER 68 -----	USER 78 -----	USER 88 -----	USER 98 -----
BASIC USERS →	USER 09 -----	USER 19 -----	USER 29 -----	USER 39 -----	USER 49 -----	USER 59 -----	USER 69 -----	USER 79 -----	USER 89 -----	USER 99 -----

MASTER CODE

SERVICE CODE 1

SERVICE CODE 2

SERVICE CODE 3

LOCK DESCRIPTION

Manager & Basic User Location Worksheet

This lock provides three types of codes: **Master** (can perform ALL functions), **Manager** (can perform SOME programming functions plus entry through the door), and **Basic User** (entry only). In total, there are 104 "locations" inside the lock: One Master Code, 10 Manager Codes, 90 Basic Codes, and three one-time entry "Service Codes". *Where the Code is located determines its programming abilities.* From the factory, all locations (except for the Master Code) are empty; each location can then be programmed to contain a code to allow users to program and/or unlock the lock to allow entry.

As a visual aid, these code locations are shown in the grid below, with ten "Banks" (columns) of ten "Managers/Basic Users" in the rows (the grid excludes the Master Code and the 3 Service Codes). Each of the 100 squares in the grid is identified by a unique two-digit location (00) through (99). Notice the two digits also specify its Bank (column) and row location in the grid. Also notice that all Managers are in the top row, their locations all ending in a zero (locations 00, 10, 20, 30 and so on through 90). Use the blank grid below as a worksheet for preparing all programming in advance. Store this worksheet in a safe place for future reference.

Each square represents a location inside the lock (excluding the Master Code and the 3 Service Codes). Each location can hold one code that can unlock the lock.

	BANK 0	BANK 1	BANK 2	BANK 3	BANK 4	BANK 5	BANK 6	BANK 7	BANK 8	BANK 9
MANAGERS →	MGR 00 -----	MGR 10 -----	MGR 20 -----	MGR 30 -----	MGR 40 -----	MGR 50 -----	MGR 60 -----	MGR 70 -----	MGR 80 -----	MGR 90 -----
BASIC USERS →	USER 01 -----	USER 11 -----	USER 21 -----	USER 31 -----	USER 41 -----	USER 51 -----	USER 61 -----	USER 71 -----	USER 81 -----	USER 91 -----
BASIC USERS →	USER 02 -----	USER 12 -----	USER 22 -----	USER 32 -----	USER 42 -----	USER 52 -----	USER 62 -----	USER 72 -----	USER 82 -----	USER 92 -----
BASIC USERS →	USER 03 -----	USER 13 -----	USER 23 -----	USER 33 -----	USER 43 -----	USER 53 -----	USER 63 -----	USER 73 -----	USER 83 -----	USER 93 -----
BASIC USERS →	USER 04 -----	USER 14 -----	USER 24 -----	USER 34 -----	USER 44 -----	USER 54 -----	USER 64 -----	USER 74 -----	USER 84 -----	USER 94 -----
BASIC USERS →	USER 05 -----	USER 15 -----	USER 25 -----	USER 35 -----	USER 45 -----	USER 55 -----	USER 65 -----	USER 75 -----	USER 85 -----	USER 95 -----
BASIC USERS →	USER 06 -----	USER 16 -----	USER 26 -----	USER 36 -----	USER 46 -----	USER 56 -----	USER 66 -----	USER 76 -----	USER 86 -----	USER 96 -----
BASIC USERS →	USER 07 -----	USER 17 -----	USER 27 -----	USER 37 -----	USER 47 -----	USER 57 -----	USER 67 -----	USER 77 -----	USER 87 -----	USER 97 -----
BASIC USERS →	USER 08 -----	USER 18 -----	USER 28 -----	USER 38 -----	USER 48 -----	USER 58 -----	USER 68 -----	USER 78 -----	USER 88 -----	USER 98 -----
BASIC USERS →	USER 09 -----	USER 19 -----	USER 29 -----	USER 39 -----	USER 49 -----	USER 59 -----	USER 69 -----	USER 79 -----	USER 89 -----	USER 99 -----

MASTER CODE

SERVICE CODE 1

SERVICE CODE 2

SERVICE CODE 3

LOCK DESCRIPTION

Manager & Basic User Location Worksheet

This lock provides three types of codes: **Master** (can perform ALL functions), **Manager** (can perform SOME programming functions plus entry through the door), and **Basic User** (entry only). In total, there are 104 "locations" inside the lock: One Master Code, 10 Manager Codes, 90 Basic Codes, and three one-time entry "Service Codes". *Where the Code is located determines its programming abilities.* From the factory, all locations (except for the Master Code) are empty; each location can then be programmed to contain a code to allow users to program and/or unlock the lock to allow entry.

As a visual aid, these code locations are shown in the grid below, with ten "Banks" (columns) of ten "Managers/Basic Users" in the rows (the grid excludes the Master Code and the 3 Service Codes). Each of the 100 squares in the grid is identified by a unique two-digit location (00) through (99). Notice the two digits also specify its Bank (column) and row location in the grid. Also notice that all Managers are in the top row, their locations all ending in a zero (locations 00, 10, 20, 30 and so on through 90). Use the blank grid below as a worksheet for preparing all programming in advance. Store this worksheet in a safe place for future reference.

Each square represents a location inside the lock (excluding the Master Code and the 3 Service Codes). Each location can hold one code that can unlock the lock.

	BANK 0	BANK 1	BANK 2	BANK 3	BANK 4	BANK 5	BANK 6	BANK 7	BANK 8	BANK 9
MANAGERS →	MGR 00 -----	MGR 10 -----	MGR 20 -----	MGR 30 -----	MGR 40 -----	MGR 50 -----	MGR 60 -----	MGR 70 -----	MGR 80 -----	MGR 90 -----
BASIC USERS →	USER 01 -----	USER 11 -----	USER 21 -----	USER 31 -----	USER 41 -----	USER 51 -----	USER 61 -----	USER 71 -----	USER 81 -----	USER 91 -----
BASIC USERS →	USER 02 -----	USER 12 -----	USER 22 -----	USER 32 -----	USER 42 -----	USER 52 -----	USER 62 -----	USER 72 -----	USER 82 -----	USER 92 -----
BASIC USERS →	USER 03 -----	USER 13 -----	USER 23 -----	USER 33 -----	USER 43 -----	USER 53 -----	USER 63 -----	USER 73 -----	USER 83 -----	USER 93 -----
BASIC USERS →	USER 04 -----	USER 14 -----	USER 24 -----	USER 34 -----	USER 44 -----	USER 54 -----	USER 64 -----	USER 74 -----	USER 84 -----	USER 94 -----
BASIC USERS →	USER 05 -----	USER 15 -----	USER 25 -----	USER 35 -----	USER 45 -----	USER 55 -----	USER 65 -----	USER 75 -----	USER 85 -----	USER 95 -----
BASIC USERS →	USER 06 -----	USER 16 -----	USER 26 -----	USER 36 -----	USER 46 -----	USER 56 -----	USER 66 -----	USER 76 -----	USER 86 -----	USER 96 -----
BASIC USERS →	USER 07 -----	USER 17 -----	USER 27 -----	USER 37 -----	USER 47 -----	USER 57 -----	USER 67 -----	USER 77 -----	USER 87 -----	USER 97 -----
BASIC USERS →	USER 08 -----	USER 18 -----	USER 28 -----	USER 38 -----	USER 48 -----	USER 58 -----	USER 68 -----	USER 78 -----	USER 88 -----	USER 98 -----
BASIC USERS →	USER 09 -----	USER 19 -----	USER 29 -----	USER 39 -----	USER 49 -----	USER 59 -----	USER 69 -----	USER 79 -----	USER 89 -----	USER 99 -----

MASTER CODE

SERVICE CODE 1

SERVICE CODE 2

SERVICE CODE 3

LOCK DESCRIPTION

ALARM LOCK LIMITED WARRANTY

ALARM LOCK SYSTEMS, INC. (ALARM LOCK) warrants its products to be free from manufacturing defects in materials and workmanship for twenty four months following the date of manufacture. ALARM LOCK will, within said period, at its option, repair or replace any product failing to operate correctly without charge to the original purchaser or user.

This warranty shall not apply to any equipment, or any part thereof, which has been repaired by others, improperly installed, improperly used, abused, altered, damaged, subjected to acts of God, or on which any serial numbers have been altered, defaced or removed. Seller will not be responsible for any dismantling or reinstallation charges, environmental wear and tear, normal maintenance expenses, or shipping and freight expenses required to return products to ALARM LOCK. Additionally, this warranty shall not cover scratches, abrasions or deterioration due to the use of paints, solvents or other chemicals.

THERE ARE NO WARRANTIES, EXPRESS OR IMPLIED, WHICH EXTEND BEYOND THE DESCRIPTION ON THE FACE HEREOF. THERE IS NO EXPRESS OR IMPLIED WARRANTY OF MERCHANTABILITY OR A WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE. ADDITIONALLY, THIS WARRANTY IS IN LIEU OF ALL OTHER OBLIGATIONS OR LIABILITIES ON THE PART OF ALARM LOCK.

Any action for breach of warranty, including but not limited to any implied warranty of merchantability, must be brought within the six months following the end of the warranty period.

IN NO CASE SHALL ALARM LOCK BE LIABLE TO ANYONE FOR ANY CONSEQUENTIAL OR INCIDENTAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED, EVEN IF THE LOSS OR DAMAGE IS CAUSED BY THE SELLER'S OWN NEGLIGENCE OR FAULT.

In case of defect, contact the security professional who installed and maintains your security system. In order to exercise the warranty, the product must be returned by the security professional, shipping costs prepaid and insured to ALARM LOCK. After repair or replacement, ALARM LOCK assumes the cost of returning products under warranty. ALARM LOCK shall have no obligation under this warranty, or otherwise, if the product has been repaired by others, improperly installed, improperly used, abused, altered, damaged, subjected to accident, nuisance, flood, fire or acts of God, or on which any serial numbers have been altered, defaced or removed. ALARM LOCK will not be responsible for any dismantling, reassembly or reinstallation charges, environmental wear and tear, normal maintenance expenses, or shipping and freight expenses required to return products to ALARM LOCK. Additionally, this warranty shall not cover scratches, abrasions or deterioration due to the use of paints, solvents or other chemicals.

This warranty contains the entire warranty. It is the sole warranty and any prior agreements or representations, whether oral or written, are either merged herein or are expressly cancelled. ALARM LOCK neither assumes, nor authorizes any other person purporting to act on its behalf to modify, to change, or to assume for it, any other warranty or liability concerning its products.

In no event shall ALARM LOCK be liable for an amount in excess of ALARM LOCK's original selling price of the product, for any loss or damage, whether direct, indirect, incidental, consequential, or otherwise arising out of any failure of the product. Seller's warranty, as hereinabove set forth, shall not be enlarged, diminished or affected by and no obligation or liability shall arise or grow out of Seller's rendering of technical advice or service in connection with Buyer's order of the goods furnished hereunder.

ALARM LOCK RECOMMENDS THAT THE ENTIRE SYSTEM BE COMPLETELY TESTED WEEKLY.

Warning: Despite frequent testing, and due to, but not limited to, any or all of the following; criminal tampering, electrical or communications disruption, it is possible for the system to fail to perform as expected. ALARM LOCK does not represent that the product/system may not be compromised or circumvented; or that the product or system will prevent any personal injury or property loss by burglary, robbery, fire or otherwise; nor that the product or system will in all cases provide adequate warning or protection. A properly installed and maintained alarm may only reduce risk of burglary, robbery, fire or otherwise but it is not insurance or a guarantee that these events will not occur. CONSEQUENTLY, SELLER SHALL HAVE NO LIABILITY FOR ANY PERSONAL INJURY, PROPERTY DAMAGE, OR OTHER LOSS BASED ON A CLAIM THE PRODUCT FAILED TO GIVE WARNING. Therefore, the installer should in turn advise the consumer to take any and all precautions for his or her safety including, but not limited to, fleeing the premises and calling police or fire department, in order to mitigate the possibilities of harm and/or damage.

ALARM LOCK is not an insurer of either the property or safety of the user's family or employees, and limits its liability for any loss or damage including incidental or consequential damages to ALARM LOCK's original selling price of the product regardless of the cause of such loss or damage.

Some states do not allow limitations on how long an implied warranty lasts or do not allow the exclusion or limitation of incidental or consequential damages, or differentiate in their treatment of limitations of liability for ordinary or gross negligence, so the above limitations or exclusions may not apply to you. This Warranty gives you specific legal rights and you may also have other rights which vary from state to state.

PROGRAMMING T2 FUNCTIONS

To program desired function, follow procedure in right column (assumes Master Code is programmed first).

FUNCTION	PRESS THESE BUTTONS ON KEYPAD
Pass Time ("Door Unlock")	Press Master Code [Enter between "02" () through "20" () "20" seconds] then press
Enable Groups	Press Master Code
Disable Groups	Press Master Code
Disable Users In Bank	Press Master or Manager Code [Enter Bank Number (0-9)]
Enable Users in Bank	Press Master or Manager Code [Enter Bank Number (0-9)]
Disable / Enable User Number (Toggle)	Press Master or Manager Code [Enter Bank Number] [Enter User Number] (wait for beeps and for the lock to re-lock)
Disable All	Press Master or Manager Code (Reset with Function 944)
Enable All	Press Master or Manager Code
Disable Users Only	Press Master or Manager Code (Reset with Function 944)

Fold on Line

T2 QUICK-REFERENCE GUIDE TO PROGRAMMING CODES AND FUNCTIONS
















































345 Bayview Avenue
Amityville, New York 11701
For Sales and Repairs 1-800-ALA-LOCK
For Technical Service 1-800-645-9440

Publicly traded on NASDAQ

Symbol: NSSC

QUICK REFERENCE GUIDE TO PROGRAMMING CODES


INSTRUCTIONS: To program desired function, follow procedure in right column.

FUNCTION	PRESS THESE BUTTONS ON KEYPAD
Restore Factory Default (Load original factory settings)	1. Remove the battery pack, and with the batteries disconnected, press any numeric key for 10 seconds and release. 2. Connect batteries and--within 3 seconds--press and hold  . After hearing 6 additional beeps, release  . Important: If you do not hear 6 beeps, you must start over at step 1.
Change Existing Master Code	[Enter Factory or Existing Master Code]    [Enter New Master Code _ _ _ _ _]  [Re-enter New Master Code _ _ _ _ _] [6 beeps = OK]. Factory Master Code MUST be re-programmed; allows lock configuration, passage and user management functions.
Add/Change Manager Codes (up to 10 Manager Codes allowed)	[Enter Master Code]  [Enter 2-digit Manager Location _ _]  . [Enter new Manager Code _ _ _ _ _] [6 beeps = OK]. Allows passage and user management functions.
Add/Change User Codes (up to 90 User Codes allowed)	Press Master or Manager Code  [Enter 2-digit Location _ _]  [Enter new User Code _ _ _ _ _] [6 beeps = OK]
Deleting Manager & User Codes	Press Master or Manager Code  [Enter Bank Number] [Enter User Number]  
Code Location Function	Press Master or Manager Code    [Enter Code to be located]
Next Free Code--Address Locator	Press Master or Manager Code    [Responds with Bank # and User #]
Service Code 1	Press Master or Manager Code      [Enter new Service Code _ _ _ _ _]
Service Code 2	Press Master or Manager Code      [Enter new Service Code _ _ _ _ _]
Service Code 3	Press Master or Manager Code      [Enter new Service Code _ _ _ _ _]
Clear Service Codes	Press Master or Manager Code     
Enable Passage Mode	Press Master or Manager Code   
Disable Passage Mode	Press Master or Manager Code   

MODEL DL 2700WP LEVER SETS PARTS LIST

Standard Cylinder and Interchangeable Core Models

Item	S Part#	Description	Item	Part #
1a	S6105-US3	Battery Cover	1 + 8	HW592-US3
1b	S6105-US5	Battery Cover	1 + 8	HW592-US5
1c	S6105-26D	Battery Cover	1 + 8	HW592-26D
1d	S6105-26	Battery Cover	1 + 8	HW592-26
1e	S6105-10B	Battery Cover	1 + 8	HW592-10B
2a	S6106-US3	Inside Lever		HW615-US3
2b	S6106-US5	Inside Lever		HW615-US5
2c	S6106-26D	Inside Lever		HW615-26D
2d	S6106-26	Inside Lever		HW615-26
2e	S6106-10B	Inside Lever		HW615-10B
Thru Bolt/10-32x2-1/2", (2)				
3a	S6104-US3	Flat Hd.,PH,MS	3+5+19	SC458-US3
3b	S6104-US5	Flat Hd.,PH,MS	3+5+19	SC458-US5
3c	S6104-26D	Flat Hd.,PH,MS	3+5+19	SC458-26D
3d	S6104-26	Flat Hd.,PH,MS	3+5+19	SC458-26
3e	S6104-10B	Flat Hd.,PH,MS	3+5+19	SC458-10B
4a	S6044-US3	Inside Housing Ass'y		
4b	S6044-US5	Inside Housing Ass'y		
4c	S6044-26D	Inside Housing Ass'y		
4d	S6044-26	Inside Housing Ass'y		
4e	S6044-10B	Inside Housing Ass'y		
Inside Mounting Screws (2)				
5a	S6104-US3	#6-32x3/8", Oval Hd	3+5+19	P1526-US3
5b	S6104-US5	#6-32x3/8", Oval Hd	3+5+19	P1526-US5
5c	S6104-26D	#6-32x3/8", Oval Hd	3+5+19	P1526-26D
5d	S6104-26	#6-32x3/8", Oval Hd	3+5+19	P1526-26
5e	S6104-10B	#6-32x3/8", Oval Hd	3+5+19	P1526-10B
6	S6115	Inside Mounting Plate	6 + 7	HW594
Inside Mounting Plate Screws (2)				
7	S6115	#8-32x1", Flat Hd,PH,MS	6 + 7	SC459
8a	S6105-US3	#4-40x1/4", Flat Hd,PH,MS	1 + 8	P5851-US3
8b	S6105-US5	#4-40x1/4", Flat Hd,PH,MS	1 + 8	P5851-US3
8c	S6105-26D	#4-40x1/4", Flat Hd,PH,MS	1 + 8	P5851-26D
8d	S6105-26	#4-40x1/4", Flat Hd,PH,MS	1 + 8	P5851-26D
8e	S6105-10B	#4-40x1/4", Flat Hd,PH,MS	1 + 8	P5851-10B
Inside Rose Screws (2)				
9	S6103	#10-32x1"w/#8PanHd,PH,MS	7 + 9	SC457
10	HW564	Inside Rose		
11	S6045	Lock Body Assembly		
11A	S6046	IC Lock Body Ass'y		
12a	S6054-US3	Outside Housing Ass'y		
12b	S6054-US5	Outside Housing Ass'y		
12c	S6054-26D	Outside Housing Ass'y		
12d	S6054-26	Outside Housing Ass'y		
12e	S6054-10B	Outside Housing Ass'y		
13a	S6111-US3	Std. Cylinder Ass'y		HW596-US3
13b	S6111-26D	Std. Cylinder Ass'y		HW596-26D
14	HW578	Cylinder Retainer		
15a	S6110-US3	Outside Lever		HW614-US3
15b	S6110-US5	Outside Lever		HW614-US5





Item	S Part #	Description	Item	Part #
15c	S6110-26D	Outside Lever		HW614-26D
15d	S6110-26	Outside Lever		HW614-26
15e	S6110-10B	Outside Lever		HW614-10B
16a	S6107-US3	Outside Lever-IC Core		HW616-US3
16b	S6107-US5	Outside Lever-IC Core		HW616-US5
16c	S6107-26D	Outside Lever-IC Core		HW616-26D
16d	S6107-26	Outside Lever-IC Core		HW616-26
16e	S6107-10B	Outside Lever-IC Core		HW616-10B
17	HW618	Lever Release Pin		
18a	S6112-US3	Latch - 2-3/4" Backset		
18b	S6112-US5	Latch - 2-3/4" Backset		
18c	S6112-26D	Latch - 2-3/4" Backset		
18d	S6112-26	Latch - 2-3/4" Backset		
18e	S6112-10B	Latch - 2-3/4" Backset		
18a	S6125-US3	Latch - 2-3/8" Backset		
18b	S6125-US5	Latch - 2-3/8" Backset		
18c	S6125-26D	Latch - 2-3/8" Backset		
18d	S6125-26	Latch - 2-3/8" Backset		
18e	S6125-10B	Latch - 2-3/8" Backset		
19a	S6104-US3	#8x3/4" Combo screw	3+5+19	SC460-US3
19b	S6104-US5	#8x3/4" Combo screw	3+5+19	SC460-US5
19c	S6104-26D	#8x3/4" Combo screw	3+5+19	SC460-26D

Item	S Part #	Description	Item	Part #
19d	S6104-26	#8x3/4" Combo screw	3+5+19	SC460-26
19e	S6104-10B	#8x3/4" Combo screw	3+5+19	SC460-10B
20a	S6114-US3	Strike 2-3/4" x 1-1/8"	20 + 27	HW577-US3
20b	S6114-US5	Strike 2-3/4" x 1-1/8"	20 + 27	HW577-US5
20c	S6114-26D	Strike 2-3/4" x 1-1/8"	20 + 27	HW577-26D
20d	S6114-26	Strike 2-3/4" x 1-1/8"	20 + 27	HW577-26
20e	S6114-10B	Strike 2-3/4" x 1-1/8"	20 + 27	HW577-10B
21	P5847	Dust Box		
22	S6070-B	IC Tail-Best,Arrow,Falcon		HW598
23	S6070-KIL	Std. Tailpiece		HW597
24	HW580	Replace tailpiece-Schlage		
25	HW620	Replace tailpiece for Lori		
26	WA160	Washer for all tailpieces		
27a	S6114-US3	Strike 4-7/8" x 1-1/4"	20+27	P5846-US3
27b	S6114-US5	Strike 4-7/8" x 1-1/4"	20+27	P5846-US5
27c	S6114-26D	Strike 4-7/8" x 1-1/4"	20+27	P5846-26D
27d	S6114-26	Strike 4-7/8" x 1-1/4"	20+27	P5846-26
27e	S6114-10B	Strike 4-7/8" x 1-1/4"	20+27	P5846-10B
28	S6040	Battery Pack Assembly		




IMPORTANT STARTUP PROCEDURE

First Time Start Up

1. Unpack the lock from its factory packaging. With batteries disconnected, hold down any number key for 10 seconds and release.
2. Connect batteries and--within 3 seconds--press and hold  button. After hearing 6 beeps, release the  button. Wait 5 seconds for lock to re-lock (listen for 1 beep and red LED). The lock is now ready to accept programming.

Important Notes: Failure to follow this exact procedure can result in erratic lock behavior. When entering any programming key sequence, *do not pause more than 5 seconds between any key presses*--otherwise you must start again. **In addition**, *no other programming commands will be accepted until the Factory Master Code has been changed* (see User Guide OI209A to change the factory Master Code). When the factory Master Code has been changed, you can then enter new manager/user codes and program other functions.



IMPORTANT

Seal all connectors with Dielectric Grease (part MX959) or Silicone Lubricant (supplied)

© ALARM LOCK 2009



ALARM LOCK

W11822A 8/09



ALARM LOCK

345 Bayview Avenue
Amityville, New York 11701
For Sales and Repairs 1-800-ALA-LOCK
For Technical Service 1-800-645-9440

(Note: Technical Service is for alarm professionals only)
Publicly traded on NASDAQ Symbol: NSSC

CORRECT WAY TO REMOVE INSIDE HOUSING FROM SPINDLE

© ALARM LOCK 2010


WI1871 5/10



Use key to depress the lever catch pin, then remove the inside handle.



Do NOT insert a screwdriver or other tool into the spindle to release the catch pin, as the catch spring is easily damaged.



Press the catch pin as shown, then pull the inside housing off spindle.