

MOUNTING TEMPLATE
For installing an Oval or Rectangular Proximity Reader to the OUTSIDE of door

- Use this template with solid wood doors only! (For fire-rated metal doors, use template WI2155)
- For use with Cylindrical Locks
- For use with a *Surface-Mounted Networkx Control Module* ("Backbox")
- Use on OUTSIDE of door

IMPORTANT
WHEN PRINTING OR PHOTO-COPYING A TEMPLATE, ALWAYS SELECT PRINTING OPTIONS TO ENSURE THAT COPIES ARE PRODUCED WITHOUT SIZE ADJUSTMENTS. VERIFY THE DIMENSIONS OF THIS BOX ARE 2.000 x 2.000 INCHES ± 0.010.

Note: The wire hole for the Oval or Rectangular Proximity Reader is located 5-5/32" from the "HORIZONTAL CENTER LINE OF LEVER" as shown.

FOLD HERE AND ALIGN TEMPLATE ON HIGH EDGE OF DOOR BEVEL (LONG SIDE OF DOOR)

FOLD HERE AND ALIGN TEMPLATE ON HIGH EDGE OF DOOR BEVEL (LONG SIDE OF DOOR)

For installation on UL Listed Wood Fire Doors fill the through hole wire passage with UL Classified Fire Stop Sealant after connecting all wiring and testing the Lock

