

MOUNTING TEMPLATE FOR THE
SURFACE-MOUNTED NETWORKX
CONTROL MODULE
(FOR MORTISE LOCKS)

USE ON PROTECTED SIDE OF
DOOR

For installation on
UL Listed Wood Fire
Doors fill the
through hole wire
passage with UL
Classified Fire Stop
Sealant after con-
necting all wiring
and testing the
Lock

FOR HIGH EDGE OF
DOOR BEVEL (LONG
SIDE OF DOOR)

FOR LOW EDGE OF
DOOR BEVEL (SHORT
SIDE OF DOOR)

NOT A THRU HOLE
USE DRILL #35 (FOR #6
SCREW) 1/2" DEEP
(CENTER HOLE FOR
NON-BEVELED DOORS)

5/8" DIAMETER NON-
THRU HOLE

NOT A THRU HOLE
USE DRILL #35 (FOR #6
SCREW) 1/2" DEEP
(CENTER HOLE FOR
NON-BEVELED DOORS)

SURFACE-
MOUNTED
NETWORKX
CONTROL
MODULE
(HW1923)

1-5/8"

1-5/8"

3-1/4"


7-5/16"

IMPORTANT

WHEN PRINTING OR PHOTO-
COPYING A TEMPLATE,
ALWAYS SELECT PRINTING
OPTIONS TO ENSURE THAT
COPIES ARE PRODUCED
WITHOUT SIZE ADJUSTMENTS.
VERIFY THE DIMENSIONS OF
THIS BOX ARE 2.000 X 2.000
INCHES ± 0.010.

HORIZONTAL CENTER LINE OF LEVER

Note: The wire hole for the reader is
located 7-5/16" from the "HORIZONTAL
CENTER LINE OF LEVER" as shown.



MOUNTING TEMPLATE FOR
THE SURFACE-MOUNTED
NETWORKX CONTROL MODULE
(FOR MORTISE LOCKS)

USE ON PROTECTED SIDE OF
DOOR

For installation on
UL Listed Wood Fire
Doors fill the
through hole wire
passage with UL
Classified Fire Stop
Sealant after con-
necting all wiring
and testing the
Lock

