


PSIREN Wireless Siren Mounting Template

For Wall Outlets With a Center Cover Plate Screw



PSIREN Wireless Siren Mounting Template

For Wall Outlets Without a Center Cover Plate Screw

This template shows the unit plugged into the bottom receptacle, but either can be used (or invert the unit as required).

Remove the two screws from the siren housing and replace screws with bracket in place, as shown.

